

Installing, starting up, and operating the AXC F 1152, AXC F 2152 and AXC F 3152 controllers

User manual

User manual

Installing, starting up, and operating the AXC F 1152, AXC F 2152 and AXC F 3152 controllers

UM EN AXC F X152, Revision 12

2023-06-30

This user manual is valid for:

Designation	As of version (HW)	As of version (FW)	Order No.
AXC F 1152	05	2020.0 LTS	1151412
AXC F 2152	05	2020.0 LTS	2404267
AXC F 3152	03	2020.3	1069208



Before starting up the controller, observe the following:

- Make sure you always operate the controller with the latest firmware version.

The current firmware version can be downloaded at:

- AXC F 1152: phoenixcontact.net/product/1151412
- AXC F 2152: phoenixcontact.net/product/2404267
- AXC F 3152: phoenixcontact.net/product/1069208

- Observe the change notes regarding the firmware version.
- If necessary, update the firmware.

For information on running firmware updates, refer to section “[Web-based management \(WBM\)](#)” on [page 69](#) and section “[Updating the firmware](#)” on [page 96](#).

Table of contents

1	For your safety	6
1.1	Identification of warning notes	6
1.2	Qualification of users	6
1.3	Field of application of the product.....	7
1.3.1	Intended use	7
1.4	Product changes	7
1.5	Safety notes	7
1.6	Security in the network	8
1.7	UL notes	9
1.7.1	AXC F 1152 and AXC F 2152	9
1.7.2	AXC F 3152	9
1.8	AXC F 2152: Installation in potentially explosive area.....	10
2	Transport, storage, and unpacking	12
2.1	Transport.....	12
2.2	Storage.....	12
2.3	Unpacking	12
3	Description of the controllers	14
3.1	General description of the controllers	14
3.2	Licensing information regarding open-source software	20
3.3	Requesting the source code.....	20
3.4	Directory structure of the file system.....	20
3.5	Using SFTP to access the file system.....	21
3.6	Firewall	22
3.7	Possible fields of application of the controller	22
3.7.1	The controller as a distributed controller of an Axioline F station	22
3.7.2	The controller as a PROFINET controller in a PROFINET network	23
3.7.3	The controller as a PROFINET device in a PROFINET network	24
3.8	Components of the controller	25
3.8.1	Connection and operating elements	25
3.8.2	Printing	27
3.9	Diagnostic and status indicators.....	29
3.10	Mode selector switch (AXC F 3152)	33
3.11	Reset button	34

3.12	Flash memory.....	36
3.13	SD card (optional).....	36
3.14	Internal basic circuit diagram	39
3.15	Ethernet interfaces	41
3.16	Supply connector.....	42
3.17	Bus base module.....	43
4	Mounting hardware	45
4.1	Safety notes	45
4.2	Basic information.....	46
4.3	Structure of an Axioline F station	48
4.4	Structure of a PLCnext Inline station.....	50
4.5	Mounting the controller.....	51
4.6	Inserting the SD card	52
4.7	Mounting a left-alignable Axioline F extension module	53
4.8	Mounting the AXC F IL ADAPT Inline adapter terminal.....	53
5	Connecting and wiring hardware	54
5.1	Supply voltage.....	54
5.1.1	Sizing of the power supply	54
5.1.2	Connecting the power supply	55
5.2	Connecting Ethernet.....	57
6	Startup	58
6.1	Installing PLCnext Engineer	58
6.2	User interface	59
6.3	Creating a new project.....	60
6.4	Configuring the IP settings.....	61
6.4.1	Setting the IP address range	61
6.4.2	Setting the IP address	63
6.5	Connecting to the controller.....	64
7	PROFICLOUD.IO	67
8	System variables and status information	68
9	Web-based management (WBM)	69
10	Removing hardware	70
10.1	Safety notes	70

	10.2 Removing cables.....	71
	10.3 Removing the connector.....	71
	10.4 Removing the SD card.....	72
	10.5 Removing the controller.....	73
	10.6 Removing a left-alignable Axioline F extension module.....	73
	10.7 Removing the AXC F IL ADAPT Inline adapter terminal	73
11	Device replacement, device defects, and repairs	74
	11.1 Device replacement.....	74
	11.2 Device defects and repair.....	75
12	Maintenance, decommissioning, and disposal	76
	12.1 Maintenance.....	76
	12.2 Decommissioning and disposal.....	76
13	Troubleshooting and frequently asked questions (FAQs)	77
14	Ordering data and technical data	78
	14.1 AXC F 1152.....	78
	14.1.1 Ordering data	78
	14.1.2 Technical data	78
	14.2 AXC F 2152.....	84
	14.2.1 Ordering data	84
	14.2.2 Technical data	84
	14.3 AXC F 3152.....	90
	14.3.1 Ordering data	90
	14.3.2 Technical data	90
A	Appendix	96
	A 1 Updating the firmware	96
	A 2 Shell commands for controlling the firmware	96
	A 3 Replacing the HTTPS certificate.....	96
	A 4 Use of the AXC F 2152 controller under extreme ambient conditions.....	97
B	Appendix for document lists.....	98
	B 1 List of figures	98
	B 2 List of tables	101
	B 3 Index.....	102

1 For your safety

Read this user manual carefully and keep it for future reference.

1.1 Identification of warning notes



This symbol indicates hazards that could lead to personal injury.

There are three signal words indicating the severity of a potential injury.

DANGER

Indicates a hazard with a high risk level. If this hazardous situation is not avoided, it will result in death or serious injury.

WARNING

Indicates a hazard with a medium risk level. If this hazardous situation is not avoided, it could result in death or serious injury.

CAUTION

Indicates a hazard with a low risk level. If this hazardous situation is not avoided, it could result in minor or moderate injury.



This symbol together with the **NOTE** signal word warns the reader of actions that might cause property damage or a malfunction.



Here you will find additional information or detailed sources of information.

1.2 Qualification of users

The use of products described in this user manual is oriented exclusively to:

- Electrically skilled persons or persons instructed by them. The users must be familiar with the relevant safety concepts of automation technology as well as applicable standards and other regulations.
- Qualified application programmers and software engineers. The users must be familiar with the relevant safety concepts of automation technology as well as applicable standards and other regulations.

1.3 Field of application of the product

1.3.1 Intended use

The AXC F 1152 and AXC F 2152 controllers are modular small-scale controllers. The AXC F 3152 is a modular controller that can be used for smaller and medium-sized applications. The devices comply with the IP20 degree of protection and are designed for use in closed control cabinets or control boxes (terminal boxes) with an IP54 degree of protection or higher.

The devices are designed for use in industrial environments.

1.4 Product changes

Modifications to the device hardware are not permitted.

Incorrect operation or modifications to the devices can endanger your safety or damage the devices. Do not repair the devices yourself. If a device is defective, please contact Phoenix Contact.

1.5 Safety notes

Observe the country-specific installation, safety, and accident prevention regulations.

**NOTE: Property damage due to impermissible stress**

The IP20 degree of protection (IEC 60529/EN 60529) requires that the device is used in a clean and dry environment. If you use the device in an environment that is outside of the specified limits, this may cause damage to the device.

- Do not subject the device to mechanical and/or thermal loads that exceed the specified limits.

**NOTE: Electrostatic discharge**

The device contains components that can be damaged or destroyed by electrostatic discharge. When handling the device, observe the necessary safety precautions against electrostatic discharge (ESD) in accordance with EN 61340-5-1 and IEC 61340-5-1.

**NOTE: Device failure due to foreign objects in device**

Foreign objects in the device can lead to malfunctions or even device failure.

- Ensure that no foreign objects find their way into the device (e.g., into the vents).

**NOTE: Device failure if operated outside the permitted ambient temperature range**

Operating the device in ambient temperatures that are not within the permitted range may lead to malfunctions or even device failure.

- Ensure that the device is operated within the permitted ambient temperature range, see [Section 14, "Ordering data and technical data"](#).



NOTE: Device failure due to vibrations and shock levels above the permitted specifications during operation

If the device is subjected to vibrations and shock levels above the permitted specifications during operation, this may lead to malfunctions or even device failure.

- Ensure that the permitted specifications for vibrations and shocks are adhered to when operating the device, see [Section 14, “Ordering data and technical data”](#).



NOTE: Device defect due to polarity reversal

Polarity reversal puts a strain on the electronics and can damage the device.

- To protect the device, avoid reversing the poles of the 24 V supply.

1.6 Security in the network



NOTE: Network security jeopardized by unauthorized access

Connecting devices to a network entails the danger of unauthorized access to the network.

Observe the following safety notes:

- If possible, deactivate unused communication channels.
- Use secure passwords reflecting the complexity and service life recommended in the latest guidelines.
- Only allow authorized persons to access the device. Limit the number of authorized persons to the necessary minimum.
- Always install the latest firmware version. The firmware can be downloaded via the item (phoenixcontact.com/products).
- Observe the IT security requirements and the standards applicable to your application. Take the necessary protective measures. These may include, for example, virtual networks for remote maintenance access or a firewall.
- In security-critical applications, always use the device with an additional security appliance.
Phoenix Contact offers security appliances in the mGuard product range. The mGuard routers connect various networks for the remote maintenance and protection of the local network and protect these networks against cyberattacks.
- You must take defense-in-depth strategies into consideration when planning networks.



Additional measures for protection against unauthorized network access can be found in the “INDUSTRIAL SECURITY” application note. The application note can be downloaded via the item (phoenixcontact.com/products).

German: AH DE INDUSTRIAL SECURITY, 107913

English: AH EN INDUSTRIAL SECURITY, 107913

If a security vulnerability exists for products, solutions, or services from Phoenix Contact, it will be published on the PSIRT (Product Security Incident Response Team) website:

phoenixcontact.com/psirt

1.7 UL notes

1.7.1 AXC F 1152 and AXC F 2152

UL Ordinary Location

- If the device is not used in the specified manner, the protection provided by the device may be impaired.
- The supply source and ext. circuits intended to be connected to this device shall be galv. separated from mains supply or hazardous live voltage using reinforced or double insulation and meet the requirements of SELV circuit of UL/IEC 61010-2-201 and clause 9.4 Limited energy circuit of UL/IEC 61010-1 or NEC Class 2.

UL Hazardous Location (nur AXC F 2152)

- Ambient temperature: $-25\text{ °C} < T_{\text{amb}} < 60\text{ °C}$
- This device must be installed in a tool only accessible enclosure certified for use in Class I, Zone 2, minimum, and rated IP54, minimum, in accordance with UL/CSA 60079-0 when used in a Class I, Zone 2 environment.
- This device must be installed within an area of not more than pollution degree 2, as defined in IEC 60664-1.
- Electrical Ratings:
 $U_L = 24\text{ V DC (19.2 V DC ... 30 V DC)} / I_{\text{max}} = 442\text{ mA}$

1.7.2 AXC F 3152

UL Ordinary Location



CAUTION:

- The external circuits intended to be connected to this device shall be galvanically separated from the mains supply or hazardous live voltage by reinforced or double insulation and meet the requirements of SELV/PELV (Class III) circuits of UL/CSA/IEC 61010-1, UL/CSA/IEC 61010-2-201.
- The device has to be installed in the final safety enclosure, which has adequate rigidity according to UL 61010-1, UL 61010-2-201 and meets the requirements with respect to spread of fire.



To install the device in accordance with UL/CSA/IEC standard, the following notes must be observed.

- If the device is not used in the specified manner, the protection provided by the device may be impaired.
- Mount and install the device in such a way that the disconnecting device can be operated without restriction.
- Minimum temperature rating and size of the cables to be connected to the field wiring terminals: min. 80°C and 24 ... 16 AWG

1.8 AXC F 2152: Installation in potentially explosive area



WARNING: Explosion hazard

- Before using the device in a potentially explosive area, make sure that your device has the required approval. The approvals are printed on the device.



WARNING: Explosion hazard

- Please make sure that the following notes and instructions are observed.
 - The category 3 device is designed for installation in zone 2 potentially explosive areas.
 - The device satisfies the requirements of the following standards:
EN/IEC 60079–0 und EN/IEC 60079–7
For detailed information, refer to the declarations of conformity enclosed with the device. For the latest version, go to the item page at www.phoenixcontact.com/product/2404267.
 - Installation, operation, and maintenance may only be carried out by qualified electricians. Follow the installation instructions as described. When installing and operating the device, the applicable regulations and safety directives (including national safety directives), as well as general technical regulations, must be observed. The safety data is listed in this document and in the certificates.
 - Observe the specified conditions for use in potentially explosive areas! Also observe the requirements of EN/IEC 60079-14.
 - The device must not be opened or modified. Do not repair the device yourself, replace it with an equivalent device. Repairs may only be carried out by the manufacturer. The manufacturer is not liable for damage resulting from violation.
 - The IP20 protection (IEC 60529/EN 60529) of the device is intended for use in a clean and dry environment. The device must not be subject to mechanical strain and/or thermal loads, which exceed the limits described.
 - The device must be stopped and immediately removed from the Ex area if it is damaged, was subject to an impermissible load, stored incorrectly or if it malfunctions.
 - In potentially explosive areas, only connect and disconnect cables and plug-in connections (e.g., connector, bus base module, SD card, etc.) when the power is disconnected.

Special conditions

- The device must be installed in a housing (switch or distributor box) that satisfies the requirements of EN/IEC 60079-0, EN/IEC 60079-7, GB 3836.1-2010 and has at least IP54 degree of protection (EN/IEC 60529).
- Use the device in an environment that does not exceed pollution degree 2 in accordance with EN/IEC 60664-1, GB/T 16935.1.
- Connect the DIN rail to the protective earth ground.
- For safe operation, lockable plug connections must have a functional interlock (e. g. locking clip, screw connection etc.). Insert the interlock. Repair any damaged connectors immediately.
- For safe operation, all interfaces on the device must be used or covered.

Areas with a danger of dust explosions

- The device is not designed for use in atmospheres with a danger of dust explosions.

Ambient temperature range

-25 °C ... 55 °C (AXC F X152)

-25 °C ... 60 °C (AXC F X152 with AXL F PWR 1H module)

Table 1-1 Temperature derating of the AXC F 2152 depending on the altitude

Altitude (above sea level)	Maximum ambient temperature AXC F X152	Maximum ambient temperature AXC F X152 + AXL F PWR 1H
Up to 2000 m	55°C	60°C
2000 m ... 3000 m	49°C	54°C
3000 m ... 4000 m	44°C	48°C
4000 m ... 5000 m	38°C	42°C

2 Transport, storage, and unpacking

2.1 Transport

The device is delivered in cardboard packaging.

- Only transport the device to its destination in its original packaging.
- Observe the instructions on how to handle the package, as well as the moisture, shock, tilt, and temperature indicators on the packaging.
- Observe the humidity specifications and the temperature range specified for transport (see [Section 14, "Ordering data and technical data"](#)).
- Protect the surfaces as necessary to prevent damage.
- When transporting the equipment or storing it temporarily, make sure that the surfaces are protected from the elements and any external influences, and that they are kept dry and clean.

2.2 Storage

The storage location must meet the following requirements:

- Dry
- Protected from unauthorized access
- Protected from harmful environmental influences such as UV light
- Temperature range: -40°C ... +85°C
- Air pressure: 58 kPa ... 106 kPa (up to 4500 m above sea level)
- Permissible humidity: 5% ... 95% (in accordance with DIN EN 61131-2)

2.3 Unpacking

The controller is supplied in packaging, together with a packing slip with installation instructions.

- Read the complete packing slip carefully before unpacking the controller.

**NOTE: Electrostatic discharge**

The device contains components that can be damaged or destroyed by electrostatic discharge. When handling the device, observe the necessary safety precautions against electrostatic discharge (ESD) in accordance with EN 61340-5-1 and IEC 61340-5-1.

**NOTE: Property damage due to noncompliance with ESD notes**

If the ESD notes are not observed during unpacking and packaging, the device may become damaged.

- Observe the ESD notes during unpacking and packaging.

Checking the delivery

- Check the delivery for transport damage.

Damaged packaging is an indicator of potential damage to the device that may have occurred during transport. This could result in a malfunction.

- Submit claims for any transport damage immediately, and inform Phoenix Contact or your supplier as well as the shipping company without delay.
- Enclose photos clearly documenting the damage to the packaging and/or delivery together with your claim.
- Immediately upon delivery, refer to the delivery note to ensure that the delivery is complete.

Scope of supply for AXC F 1152 and AXC F 2152

- Controller AXC F 1152 or AXC F 2152
- AXL BS BK bus base module
- AXL CN S/UL supply connector

Scope of supply for AXC F 3152

- AXC F 3152 controller
- AXC BS L 30 bus base module
- AXL CN S/UL supply connector

3 Description of the controllers

3.1 General description of the controllers

The AXC F 1152 and AXC F 2152 controllers are modular small-scale controllers. The AXC F 3152 is a modular controller with an integrated Ethernet and Axioline F local bus connection.

The controllers consist of an electronics module (1) and a bus base module (2).




Figure 3-1 Components of the controller

Axioline F station

An Axioline F station is created by connecting Axioline F modules to the controller. The Axioline F local bus (referred to as local bus in this document) is implemented by arranging bus base modules side by side.

Inline station

As an alternative to an Axioline F station, you can create a PLCnext Inline station using the controller. To do so, you need the AXC F IL ADAPT Inline adapter terminal (Order No. 1020304). You can directly align the Inline modules to the Inline adapter terminal.

IoT device and RTU

The main application area of the controller is industrial automation. Due to its open system architecture, it is also used as an IoT device or remote terminal unit (RTU).

Programming

The controllers can be configured and programmed in accordance with IEC 61131 using the PLCnext Engineer automation software. In addition or as an alternative to the programming languages specified in IEC 61131-3, you can also use the C++ or MATLAB® Simulink® programming languages. The individual programs or program parts can be programmed in any development environment (e.g., Eclipse, Microsoft® Visual Studio®, etc.). These programs or program parts must then be imported into PLCnext Engineer as a library.

Integrated Ethernet interfaces

The AXC F 1152 and AXC F 2152 controllers feature two switched Ethernet interfaces for TCP/IP / UDP/IP communication within the Ethernet network. The AXC F 3152 controller features three independent Ethernet interfaces for TCP/IP / UDP/IP communication within the Ethernet network.

**PROFINET controller/
device functionality**

The PROFINET protocol can be used via the Ethernet interfaces of the controllers. In this case, the controller can be used as a PROFINET controller or PROFINET device, depending on the configuration.



For additional information on how to integrate your controller as a PROFINET controller or device, please refer to the PLCnext Engineer online help.

Axioline F local bus

There is an interface to the Axioline F local bus on the bottom of the controller. Bus base modules are used to carry the communications voltage and the bus signals from the controller through the Axioline F station. A bus base module is supplied with the controllers.

Up to 63 Axioline F modules can be connected to the controllers. The modules are connected to the right of the controller. The maximum number of modules that can be operated depends on the current consumption of the modules. The total current consumption of all devices connected to the controller must not exceed the maximum current that the controller supplies for the local bus.

**NOTE: Electronics may be damaged when overloaded**

Observe the current consumption of each device when configuring an Axioline F station. The current consumption is specified in each module-specific data sheet and may vary. The possible number of devices that can be connected depends on the structure of the Axioline F station.

**Left-alignment of
Axioline F extension
modules**

In principle, you can extend the controllers by connecting Axioline F modules on the right. Furthermore, you can also add hardware functions to the left of the controller AXC F 2152 and AXC F 3152 devices.

The following left-alignable modules (extension modules) are currently available:

Available at the time this user manual was created:

- 2403115 AXC F XT ETH 1TX Left-alignable Ethernet interface
- 2403018 AXC F XT IB Left-alignable INTERBUS master
- 1139999 AXC F XT EXP Left-alignable PCIe extension interface
- 1091657 AXC F XT PB Left-alignable PROFIBUS master
- 1159811 AXC F XT SPLC 1000 Left-alignable safety-related Axioline F controller of performance class 1000
- 1259849 AXC F XT ML 1000 Left-alignable module with machine learning function

In preparation:

- 1160157 AXC F XT SPLC 3000 Left-alignable safety-related Axioline F controller of performance class 3000

Note the following special characteristics:

Table 3-1 Special characteristics of the left-alignable extension modules in combination with the controllers

Characteristic	AXC F 2152	AXC F 3152
Bus base module		
– Connection of an AXC F XT ... to the controller	Replace the bus base module of the controller with the bus base module AXC BS L 2, Order No. 1064312.	Remove the cap on the left-hand side on the bus base module of the controller.
– Connection of an AXC F XT ... to an AXC F XT ...	To align an additional AXC F XT ... module to the left on an AXC F XT ..., remove the cap on the bus base module of the preceding module.	
Extendibility		
– Direct on the controller (without AXC F XT EXP)	1 AXC F XT ... module	2 AXC F XT ... modules
– When using an AXC F XT EXP	4 AXC F XT ... modules Sequence: Module 1: AXC F XT EXP Modules 2 ... 4: Any*	5 AXC F XT ... modules Sequence: Module 1: Any* Module 2: AXC F XT EXP Modules 3 ... 5: Any*
*Restrictions		
– General	All left-alignable modules may only be connected once.	
– AXC F XT IB	If you use the module AXC F XT IB to the left, do not use an AXC F IL ADAPT in the Axioline F local bus, and vice versa.	
– AXC F XT ML 1000	With the AXC F XT ML 1000 left-alignable machine learning module, you can only extend a controller of the type AXC F 3152.	

The LED EXT on the controller signals that left-alignable extension modules are being used. The displays have the following meaning:

Designation	Color	Meaning	State	Description
EXT	Red	Left alignment	On	Error at extension module Possible error causes: – Extension module is not supported. – Extension module is not mounted correctly or is defective. – Extension module was disconnected from power during operation or has been removed.
	Green		On	Extension module operating without errors.

Please note for mounting and supplying with power:

- Mount all the modules required before supplying power to the Axioline F station. Modules to which power is only supplied following the controller boot process are not detected or may result in a malfunction.
- Feed the supply voltage for the left-alignable modules and the controller used via a common power supply unit. This ensures that the devices have the same reference potential.

- Fuse the power supply unit appropriately for the current consumption of the installation system.
- Do not reverse the supply voltage connection. The GND potential of the controller and the left-aligned extension modules are connected together via the bus base. Reversing the polarity will lead to an immediate short circuit.

- To ensure that the left-alignable extension modules are detected correctly, proceed as follows:
 - Switch on the power to the left-alignable extension modules before switching on the power to controller
or
 - Switch on the power to the left-alignable modules and to the controller simultaneously.



Always observe:

- The information in [Section “Connecting and wiring hardware” on page 54](#).
- The information in the documentation for the modules used, particularly if you are using left-alignable safety-related Axioline F controllers.

**Axioline F/
system and firmware**

For system-specific information on the Axioline F system, please refer to the PLCnext Engineer online help and the “Axioline F: System and installation” (UM EN AXL F SYS INST) and “Axioline F: Diagnostic registers and error messages” (UM EN AXL F SYS DIAG) user manuals.
The user manuals can be downloaded at phoenixcontact.com/product/2404267.

**MRP (only AXC F 1152 and
AXC F 2152)**

The MRP (Media Redundancy Protocol) can be used via the Ethernet interfaces of the controller. The controller supports the MRP client function, which can be enabled or disabled via an engineering tool (e.g., PLCnext Engineer). This function is disabled in delivery state. If the function is enabled, it remains enabled after the supply voltage is switched off and on. If the controller has been reset to the delivery state, the MRP client function will also be disabled again. In a ring with Media Redundancy Protocol, maximum switch-over times of up to 200 ms can be expected.

Flash memory/SD card

The controllers have an internal flash memory. This memory can be used to store programs and configurations which belong to your project, e.g., the visualization project. If the internal flash memory is not large enough for your application, the controllers can be operated using an SD card. The SD card is optional and not required to operate the controllers.



The SD card is not included in the scope of delivery of the controller.

- Only use an SD card provided by Phoenix Contact (see [Section “Ordering data and technical data” on page 78](#)).



NOTE: Damage to the SD card after formatting

The SD card is already formatted (ext4 format) and is intended for use with Phoenix Contact controllers of the PLCnext Control product family. If you format the SD card, certain information on the SD card that is required for use with Phoenix Contact devices will be lost. After formatting, you can no longer use the SD card to operate the controller.

- Ensure that the SD card is not formatted.

Data buffering/backup in the event of voltage failures

In the event of a supply voltage failure, the AXC F 3152 saves control data, e.g., retain data and log files, on the inserted SD card.

The device firmware recognizes the voltage failure. The retain data (variables of the controller that are marked as “Retain” in the PLCnext Engineer project) and log files are automatically backed up on the SD card.

**NOTE: Startup of the AXC F 3152 not ensured**

For proper startup of the device, the supply voltage may be switched on at the earliest 30 seconds after the diagnostic and status indicators go out.

Visualization

You can create visualizations for the controller using the HMI integrated in PLCnext Engineer.

Real-time clock

In the event that the supply voltage fails, the real-time clock integrated in the controllers is buffered, see [Section “Ordering data and technical data” on page 78](#).

Function extensions using PLCnext apps

You can easily extend the scope of functions of the controllers using apps from the PLCnext Store.

Visit the PLCnext Store at plcnextstore.com.

3.2 Licensing information regarding open-source software

The controllers work with a Linux operating system.

License information for the individual Linux packages can be found in the file system of the controller under:

`/usr/share/common-licenses`



Information on the directory structure of the file system can be found in [Section 3.4](#).

Alternatively, you can also call up the license information via the web-based management system of the controller, see [Section 9](#).

Notes on LGPL software libraries

All open-source software used in the product is subject to the respective license terms that are not affected by the Phoenix Contact Software License Terms (SLT) for the product. In particular, the license holder can change the respective open-source software in accordance with the applicable license terms. If the license holder wishes to change an LGPL software library contained in this product, reverse engineering is permitted for debugging such modifications.

Notes on OpenSSL

This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit. (<http://www.openssl.org/>).

This product includes cryptographic software written by Eric Young (eay@cryptsoft.com).

3.3 Requesting the source code

The controllers contain software components that are licensed by the rights holder as free software or open-source software under the GNU General Public License.

You can request the source code of these software components in the form of a CD or DVD-ROM for a processing fee of 50 euros within three years after delivery of the controller. To do so, contact the Phoenix Contact After Sales Service in writing at the following address:

PHOENIX CONTACT GmbH & Co. KG
 After Sales Service
 Flachsmarktstraße 8
 32825 Blomberg
 GERMANY

Subject: "Source Code AXC F 1152", "Source Code AXC F 2152", or "Source Code AXC F 3152"

3.4 Directory structure of the file system

The controllers work with a Linux operating system. You can access the controller via SFTP or via SSH and view the directories and files on the file system (on the internal flash memory and on the optional SD card) and modify them as necessary.



Information on the directory structure of the file system can be found at the [PLCnext Info Center](#).

3.5 Using SFTP to access the file system

The file system (on the internal flash memory and on the SD card of the controller) is accessed via the SFTP protocol. An SFTP client software is required for this (e.g., WinSCP).

Access to the file system via SFTP requires authentication with a user name and password.



Please note:

Authentication with a user name and password is **always** required for SFTP access and cannot be deactivated.


Only users with administrator rights can access the file system.

You can create additional users with administrator rights in the web-based management system of the controller. For additional information, please refer to the [PLCnext Info Center](#).

In the delivery state, the following access data with administrator rights is preset:

User name: admin

Password: printed on the controller (see [Figure 3-2](#)).



AXC F 1152 and AXC F 2152

AXC F 3152

Figure 3-2 Administrator password on the controller

3.6 Firewall



The firewall of the controller is deactivated by default.

Recommended:

- Activate the firewall.

For information on the firewall, please refer to the [PLCnext Info Center](#).

3.7 Possible fields of application of the controller

3.7.1 The controller as a distributed controller of an Axioline F station

The controller can be used as a distributed controller of an Axioline F station that is connected to an Ethernet system. A maximum of 63 devices (Axioline F modules) can be connected to the controller. The maximum number of alignable devices depends on the current consumption of the devices. The total current consumption of all devices aligned on the controller must not exceed the maximum current that the controller supplies for the local bus (1 A at an ambient temperature $\leq 55^{\circ}\text{C}$). If the current consumption exceeds the maximum current, use the AXL F PWR 1H power module.




Figure 3-3 Example: Axioline F station with AXC F 2152 controller

3.7.2 The controller as a PROFINET controller in a PROFINET network

Figure 3-4 shows the example of the AXC F 3152 controller as a PROFINET controller in a PROFINET network.




Figure 3-4 Example: AXC F 3152 controller as PROFINET controller

Key:

- A** PROFINET controller (AXC F 1152, AXC F 2152 or AXC F 3152)
- B** PROFINET device and switch (in the example: controller with connected Axioline F I/O modules)



For additional information on how to integrate the controller as a PROFINET controller into a PROFINET network, please refer to the PLCnext Engineer online help.

3.7.3 The controller as a PROFINET device in a PROFINET network

Figure 3-5 shows the example of the controller as a PROFINET device in a PROFINET network.




Figure 3-5 Example: AXC F 3152 controller as PROFINET device

Key:

- A** PROFINET controller (in the example: RFC 4072S)
- B** Managed switch (in the example: FL SWITCH SMCS ...)
- C** PROFINET device (AXC F 1152, AXC F 2152 or AXC F 3152)



For additional information on how to integrate the controller as a PROFINET device into a PROFINET network, please refer to the PLCnext Engineer online help.

3.8 Components of the controller

3.8.1 Connection and operating elements

AXC F 1152 and AXC F 2152




Figure 3-6 Connection and operating elements of the AXC F 1152 and AXC F 2152 controllers

The controller consists of the following components:

- 1 Bus base module
- 2 Electronics module
- 3 Reset button
- 4 SD card holder



The SD card is optional and not supplied as standard with the controller.
Please refer to the ordering data in [Section "Ordering data and technical data" on page 78](#).

- 5 Diagnostic and status indicators
- 6 Ethernet interfaces (X1, X2)
- 7 Supply connector (connector for connecting the supply voltage (communications voltage U_L))

AXC F 3152




Figure 3-7 Connection and operating elements of the AXC F 3152 controller

The controller consists of the following components:

- 1 Bus base module
- 2 Diagnostic and status indicators
- 3 Electronics module
- 4 Reset button
- 5 SD card holder



The SD card is optional and not supplied as standard with the controller. Please refer to the ordering data in [Section "Ordering data and technical data" on page 78](#).

- 6 Mode selector switch
- 7 Service interface (X4) (currently without function)
- 8 Ethernet interfaces (X1, X2, X3)
- 9 Supply connector (connector for connecting the supply voltage (communications voltage U_L))

3.8.2 Printing

AXC F 1152 and AXC F 2152 controller printing




Figure 3-8 AXC F 1152 and AXC F 2152 controller printing

AXC F 3152 controller printing




Figure 3-9 AXC F 3152 controller printing

Administrator password

You need the administrator password (in combination with the “admin” user name) for initial access to:

- The controller file system
- Certain functions in PLCnext Engineer
- The PLCnext Engineer HMI
- Web-based management (WBM)
- The OPC UA server of the controller



Recommended:

- Only use the administrator password for initial access.
- Once you have gained access successfully, change the administrator password to prevent unauthorized administrator access (see [Section 9](#)).

QR code for connecting to the PLCnext Community

You can access the PLCnext Community directly via the QR code.

In the PLCnext Community, you will find:

- Information on PLCnext Technology
- Information on PLCnext Engineer
- Information on programming the controller with C++
- Operating instructions
- Tutorials
- Example projects
- FAQs

3.9 Diagnostic and status indicators

The diagnostic and status indicators are used for quick local error diagnostics.




Figure 3-10 Diagnostic and status indicators

Table 3-2 Controller diagnostic and status indicators

Designation	Color	Meaning	State	Description
PN: PROFINET controller/device function				
BF-C	Red/yel-low	Status of PROFINET communication/communication error	Controller as PROFINET controller	
			Off	The controller has established an active communication connection to each configured PROFINET device.
			Red on	No link status on the Ethernet interfaces and/or no 100 Mbit transmission and/or no full duplex mode.
			Flashing red (1 Hz)	Link status present, at least one configured PROFINET device does not have a communication connection.
			Flashing yellow (0.5 Hz)	Flashing for device identification
BF-D	Red/yel-low	Status of PROFINET communication/communication error	Controller as PROFINET device	
			Off	A PROFINET controller has established an active communication connection to the controller (PROFINET device).
			Red on	No PROFINET communication (no link status at the Ethernet interfaces)
			Flashing red (1 Hz)	Link status present, no communication connection to the PROFINET controller
			Flashing yellow (0.5 Hz)	Flashing for device identification
SF	Red	Group error (PROFINET)	Off	PROFINET diagnostics not present
			On	PROFINET diagnostics present

Table 3-2 Controller diagnostic and status indicators

Designation	Color	Meaning	State	Description
PLC: Controller diagnostics				
RUN	Green	Controller RUN status	Off	PLCnext runtime system is not ready for operation.
			Flashing (0.5 Hz)	PLCnext runtime system successfully initialized. The controller is in the READY/STOP state; application program is not being processed.
			Flashing (2 Hz)	Controller has been reset to the default status (see Section "Reset button" on page 34).
			Flashing (2 Hz)	System watchdog was triggered. FAIL flashes red with same frequency.
			On	PLCnext runtime system successfully initialized and an application program is running. The controller is in the RUN state.
FAIL	Red	Failure	On	A runtime error has occurred in the application program of the PLCnext runtime system.
			Off	No runtime error has occurred in the application program of the PLCnext runtime system.
			Flashing (2 Hz)	System watchdog was triggered. RUN flashes green at the same frequency.
DBG	Yellow	Debug mode (troubleshooting)	On	The PLCnext runtime system/controller is in debug mode, i.e., debug mode has been activated in PLCnext Engineer (breakpoint(s) set). The status of the RUN LED is not affected.
BOOT	Red	Device firmware loading status	On	Device firmware is faulty.
			Flashing (2 Hz)	Device firmware is being loaded (boot process).
			Off	Device firmware running.

Table 3-2 Controller diagnostic and status indicators

Designation	Color	Meaning	State	Description
AXC: Axioline F diagnostics				
D	Red/yellow/green	Axioline F: diagnostics for local bus communication	Green on	Run: The Axioline F station is ready for operation; communication within the Axioline F station is OK. All data is valid. No malfunction occurred.
			Flashing green	Active: The Axioline F station is ready for operation; communication within the Axioline F station is OK. The data is not valid. There is no valid data available from the controller. No malfunction occurred on the device.
			Yellow on	Ready: The Axioline F station is ready for operation; no data is being exchanged.
			Flashing yellow	Access from Startup+ in I/O check mode
			Flashing yellow/red	Local bus error during active I/O check
			Flashing red	Local bus error during startup Possible causes: <ul style="list-style-type: none"> – Configuration cannot be generated, information is missing from a device – Chip version of a device is <V 1.1 – Desired configuration and actual configuration differ – No local bus device connected – The maximum number of local bus devices has been exceeded.
			Red on	Bus error in RUN state The Axioline F station is ready for operation but has lost connection to at least one local bus device. Possible causes: <ul style="list-style-type: none"> – Communication error – Local bus device has been removed or configured local bus device is missing – Reset at a local bus device – Serious device error at a local bus device (local bus device can no longer be reached)
Off	Power down: Local bus device is in (power) reset			
E	Yellow/red	Error/warning	Yellow on	I/O warning at a local bus device
			Red on	I/O error at a local bus device

Table 3-2 Controller diagnostic and status indicators

Designation	Color	Meaning	State	Description
EXT	Red/yellow/green	Left alignment	Off	No extension module available
			Red on	Error at extension module Possible error causes: <ul style="list-style-type: none"> – Extension module is not supported. – Extension module is not mounted correctly or is defective. – Extension module was disconnected from power during operation or has been removed.
			Yellow on	Test of the extension module during the boot procedure
			Green on	Extension module operating without errors.
PWR: Supply voltage (communications voltage U_L)				
UL	Green	U _{Logic}	Off	24 V communications voltage feed-in not present or too low
			On	24 V communications voltage feed-in present
ETH: Ethernet interfaces				
	Green	Link status	Off	Connection not established successfully
			On	Connection established successfully (link): The controller is able to contact another network device.
	Yellow	Activity status	Off	Data transmission not active
			On/flashing	Data transmission active (activity): The Ethernet interface is sending or receiving data.



Please note:

On the AXC F 1152, the EXT LED is without function as AxioLine F extension modules cannot be aligned to the left.



Special case: firmware update

During a firmware update, the RUN LED first flashes, and then stops. Upon a successful controller restart, the RUN LED lights up again permanently. Information on firmware updates can be found in [Section “Replacing the HTTPS certificate” on page 96](#).



Special cases: SD card

In the following cases, all LEDs except the D and E LEDs begin to flash red (1 Hz):

- Unauthorized removal of the SD card during operation
- Invalid SD card license
- SD card with write protection enabled

Information on operating the controller with an SD card can be found in [Section “SD card \(optional\)” on page 36](#).

3.10 Mode selector switch (AXC F 3152)




Figure 3-11 Mode selector switch on the AXC F 3152 controller


The mode selector switch is used to define the operating state of the controller.

The RUN/PROG and STOP positions have a latching function and the MRESET position has a pushbutton function. After releasing the switch in the MRESET position, it returns to the STOP position.


Table 3-3 Controller operating modes

Operating mode	Explanation
RUN/PROG	<p>The controller is in the RUN state. The application is processed.</p> <p>The PLCnext Engineer software can be used for program and configuration modifications as well as for the online monitoring function.</p> <div style="border: 1px solid black; padding: 5px; display: inline-block;"> <p>i The application is not processed if a controller error has occurred or if the application has been stopped by PLCnext Engineer.</p> </div>
STOP	<p>The controller is in the STOP state. Application processing has been stopped.</p>
MRESET	<p>The retain data and the application program in the controller RAM are deleted.</p> <p>To delete the retain data and the application program, proceed as follows:</p> <ul style="list-style-type: none"> • Hold the mode selector switch in the MRESET position for three seconds. • Release the mode selector switch for less than three seconds. • Hold the mode selector switch in the MRESET position for three seconds.

3.11 Reset button



AXC F 1152 and AXC F 2152



AXC F 3152

Figure 3-12 Reset button (1)

The reset button on the controller can only be operated with a pointed object, such as a pin, and is therefore protected against accidental activation.

If the reset button is actuated during operation for ≥ 2 s, the controller is restarted.

The reset button can also be used to reset the controller to the default settings. Here, a distinction is made between two types of default settings:

- Type 1:
All application-specific data is deleted.
- Type 2:
The controller is reset to the delivery state.



Please note the following when using PROFICLOUD:

Upon reset to default setting type 1 or 2, the controller can no longer be reached by PROFICLOUD. To continue using the controller in PROFICLOUD, proceed as follows:

- Delete the controller from PROFICLOUD, as described in the “Startup and operation of hardware and software components of the PROFICLOUD” user manual.
- Then reregister the controller in PROFICLOUD and add it as a PROFICLOUD device, as described in [Section “PROFICLOUD.IO” on page 67](#).

Default setting type 1

Resetting the controller to default setting type 1 deletes all settings that you have configured. These include, for example:

- The PLCnext Engineer project, including all applications that have been programmed in accordance with IEC 61131-3
- All applications that were programmed using high-level languages
- The configured bus configuration
- The network configuration of the controller
- Changes and extensions that you have made to the operating system or to the firmware

To reset the controller to default setting type 1, proceed as follows:

- Switch off the supply voltage of the controller.
- After the LEDs have gone out, press the reset button.
- Hold the reset button down and switch the supply voltage on.

The RUN and FAIL LEDs light up.

- Release the reset button.

The controller is reset to default setting type 1.




Figure 3-13 Sequence when resetting to default setting type 1, and LED indicators

Default setting type 2

Resetting to default setting type 2 resets the controller to the delivery state. This deletes all settings that you have configured.



Please note:

The operating system and all firmware components of the controller are reset to the delivery state.

To reset the controller to default setting type 2, proceed as follows:

- Switch off the supply voltage of the controller.
- After the LEDs have gone out, press the reset button.
- Hold the reset button down and switch the supply voltage on.

The RUN and FAIL LEDs light up.

- Press and hold the Reset button down (approx. 30 s) until all LEDs (except the E and D LEDs) light up.
- Release the reset button.

The controller is reset to default setting type 2.




Figure 3-14 Sequence when resetting to default setting type 2, and LED indicators

3.12 Flash memory



NOTE: Damage of the internal flash memory due to high data traffic

Frequent write accesses in applications with high data traffic can cause long-term damage to the internal flash memory of the controller (e.g. DataLogger applications). This leads to a device defect.

Use an external SD card as storage medium for applications with high data traffic. Phoenix Contact recommends the SD cards SD FLASH 8GB PLCnext Memory, order no. 1061701 or SD FLASH 2GB PLCnext Memory order no. 1043501.

The controllers have an internal flash memory. Alternatively, a pluggable SD card can be used, see [Section 3.13](#).

The programs and configurations (e.g., controller IP address) belonging to your PLCnext Engineer project are stored in the flash memory. In addition, application-specific data can also be stored in the flash memory.

If you make changes to Linux operating system files on the internal flash memory, the Linux operating system generates an overlay file system from the changed files and directories. If you operate the controller with an SD card, the overlay file system is generated on the SD card.

On the internal controller flash memory, the following data quantities are available for user-specific data and the overlay file system:

- 512 Mbyte on the AXC F 1152 and AXC F 2152 controllers
- 1 GB on the AXC F 3152 controller

3.13 SD card (optional)

If the internal flash memory is not large enough for your application, the controller can be operated using an SD card. The SD card is optional and not required to operate the controller.

If you operate the controller with an SD card, all application-specific data (e.g., the PLCnext Engineer project) is stored there.



The SD card will be recognized during the initialization phase of the controller. If you insert the SD card during operation, the SD card will not be recognized.

- Make sure that the SD card has been inserted before switching on the controller, in order to enable the controller to use it.
- Insert and remove the SD card only when the controller supply voltage is disconnected.
Refer to [Section “Diagnostic and status indicators” on page 29](#) for the LED blink codes in the event of unauthorized removal of the SD card during operation.
- Only use an SD card provided by Phoenix Contact, see [Section “Ordering data and technical data” on page 78](#).

**Please note:**

You can activate or deactivate support of the SD card via the WBM of the controller, see [Section 9](#).

Recommended:

- Deactivate the support of the SD card if you run the controller without SD card.

You thereby avoid the risk of data theft and manipulation.

Data buffering/backup in the event of voltage failures

In the event of a supply voltage failure, the AXC F 3152 saves control data, e.g., retain data and log files, on the inserted SD card.

The device firmware recognizes the voltage failure. The retain data (variables of the controller that are marked as “Retain” in the PLCnext Engineer project) and log files are automatically backed up on the SD card.

**NOTE: Startup of the AXC F 3152 not ensured**

For proper startup of the device, the supply voltage may be switched on at the earliest 30 seconds after the diagnostic and status indicators go out.

Change: Operation without SD card → Operation with SD card

When changing from operation without SD card to operation with SD card, note the following:

If there already is an overlay file system on the internal flash memory, it will be copied to the SD card.

If there already is an overlay file system on the SD card, the controller will access it. The overlay file system on the internal flash memory will be deleted.

Furthermore, all application-specific data will be deleted from the internal flash memory. PLCnext Engineer projects and IP configurations stored on the flash memory are no longer available. The controller accesses the data stored on the SD card.

**NOTE: Data loss due to removing the SD card**

If you remove the SD card during operation, data will be lost.

- Do not remove the SD card during operation.

**NOTE: Damage to the SD card after formatting**

The SD card is already formatted (ext4 format) and is intended for use with Phoenix Contact controllers of the PLCnext Control product family. If you format the SD card, certain information on the SD card that is required for use with Phoenix Contact devices will be lost. After formatting, you can no longer use the SD card to operate the controller.

- Ensure that the SD card is not formatted.
- If you want to delete the overlay file system from the SD card:
Reset the controller to default setting type 1.



The SD card will be recognized during the initialization phase of the controller. If you insert the SD card during operation, the SD card will not be recognized.

- Make sure that the SD card has been inserted before switching on the controller, in order to enable the controller to use it.
- Insert and remove the SD card only when the controller supply voltage is disconnected.
Refer to [Section “Diagnostic and status indicators” on page 29](#) for the LED blink codes in the event of unauthorized removal of the SD card during operation.
- Only use an SD card provided by Phoenix Contact, see [Section “Ordering data and technical data” on page 78](#).



Please note:

The SD card can be read with a conventional SD card reader at any time. Sensitive data on the SD card can be read if you do not physically protect the SD card against unauthorized access.

- Ensure that unauthorized persons do not have access to the SD card.

Change: Operation with SD card → Operation without SD card

If you want to switch from operation with SD card to operation without SD card, please note the following:

If there is an overlay file system on the SD card, there will be an empty overlay file system on the internal flash memory after the SD card has been removed and the controller re-booted. The contents of the overlay file system on the SD card will not be transferred to the internal flash memory of the controller.

Neither will the application-specific data on the SD card be transferred to the internal flash memory of the controller.

3.14 Internal basic circuit diagram

AXC F 1152 and AXC F 2152




Figure 3-15 Internal basic circuit diagram for AXC F 1152 and AXC F 2152

Key:

	Microprocessor		Transmitter
	Reset button		LED
	RJ45 interface		Real-time clock
	Functional ground connection		Power supply unit
	SD card holder		Ethernet switch
Extension bus	Left-aligned Axioline F extension modules (AXC F 2152 only)		Axioline F local bus

The colored areas in the basic circuit diagram represent electrically isolated areas:

	Logic
	Ethernet interface
	Functional ground

AXC F 3152




Figure 3-16 Internal basic circuit diagram AXC F 3152

Key:

	UPS		Mode selector switch
Reset	Reset button		Transmitter
	RJ45 interface		LED
FE	Functional ground connection		Real-time clock
SD	SD card holder		Power supply unit
Extension bus	Left-aligned Axioline F extension modules		Chipset
CPU	Processor		Axioline F local bus
FAN	Fan connection		

The colored areas in the basic circuit diagram represent electrically isolated areas:

- Logic
- Ethernet interface
- Functional ground

3.15 Ethernet interfaces

**AXC F 1152 and
AXC F 2152**

2 x Ethernet: X1/X2: 10/100 BASE-T(X) (switched internally)

Name	Interface	Default IP address
X1/X2	Ethernet interface (PROFINET)	192.168.1.10
	Ethernet interface extension module AXC F XT ETH 1TX	192.168.2.10




Figure 3-17 Ethernet interfaces (1)

AXC F 3152

3 x Ethernet: X1/X2/X3: 10/100/1000 BASE-T(X)

Name	Interface	Default IP address
X1	Ethernet interface	192.168.1.10
X2	PROFINET controller interface	192.168.2.10
X3	PROFINET device interface	192.168.3.10
	Ethernet interface extension module AXC F XT ETH 1TX	192.168.4.10




Figure 3-18 Ethernet interfaces (1)



The default IP addresses are also set after a reset to default setting type 2.

The Ethernet network is connected via RJ45 sockets:

- Use an Ethernet cable that complies with at least CAT5 of IEEE 802.3.
- Observe the bending radii of the Ethernet cables used.

3.16 Supply connector




Figure 3-19 Terminal points for the supply voltage (communications voltage U_L)

Terminal point assignment

Table 3-4 Terminal point assignment of the supply connector

Terminal point	Color	Assignment
a1, a2	Red	24 V DC (U_L)
b1, b2	Blue	GND

Key:

- U_L Communications voltage feed-in (bridged internally)
- GND Supply voltage reference potential (bridged internally)

3.17 Bus base module

AXC F 1152 and AXC F 2152

AXL BS BK bus base module

Bus base modules carry the communications voltage and the bus signals from the controller through the Axioline F station (local bus). The AXL BS BK bus base module is supplied with the **AXC F 1152 and AXC F 2152 controllers**.




Figure 3-20 Structure of the AXL BS BK bus base module

- 1 Bus base module
- 2 Connection of the local bus to the controller
- 3 Connection to the bus base module of the local bus

AXC BS L 2 bus base module (AXC F 2152 only)

For an Axioline F extension module to be aligned to the left, the AXC F 2152 requires the AXC BS L 2 bus base module. The bus base module is not supplied with the controller. Please refer to the ordering data in [Section "Ordering data and technical data" on page 78](#).




Figure 3-21 Structure of the AXC BS L 2 bus base module

- 1 Connection to the bus base module of a left-alignable Axioline F extension module
- 2 Bus base module
- 3 Connection of the extension bus to the controller
- 4 Connection of the local bus to the controller
- 5 Connection to the bus base module of the local bus

AXC F 3152

AXC BS L 30 bus base module

Bus base modules carry the communications voltage and the bus signals from the controller through the Axioline F station (local bus). The AXC BS L 30 bus base module is supplied with the AXC F 3152 controller.




Figure 3-22 Structure of the AXC BS L 30 bus base module

- 1 Connection to the bus base module of a left-alignable Axioline F extension module
- 2 Bus base module
- 3 Connection of the extension bus to the controller
- 4 Connection of the local bus to the controller
- 5 Connection to the bus base module of the local bus

4 Mounting hardware



For basic information on the Axioline F system and its installation, particularly mounting/removing Axioline F modules, please refer to the UM EN AXL F SYS INST user manual ("Axioline F: system and installation").

4.1 Safety notes



NOTE: Electrostatic discharge

The device contains components that can be damaged or destroyed by electrostatic discharge. When handling the device, observe the necessary safety precautions against electrostatic discharge (ESD) in accordance with EN 61340-5-1 and IEC 61340-5-1.



NOTE: Damage to electronics due to inadequate external protection – no safe fuse tripping in the event of a fault

The electronics in the device will be damaged if external fuse protection is inadequate.

- Protect the supply voltage externally in accordance with the connected load (number of Axioline F devices/amount of logic current consumption for each device).
- Ensure that the external fuse trips reliably in the event of a fault.



NOTE: Damage to the contacts when tilting

Tilting the modules can damage the contacts.

- Place the modules onto the DIN rail **vertically** (see [Figure 4-1](#)).



Please note:

During any work on the Axioline F station, the controller or a module, switch off the power supply to the Axioline F station and make sure the supply voltage is protected against unauthorized reactivation.



The controller is automatically grounded (FE) when it is snapped onto a grounded DIN rail.

There are two FE springs on the back of the controller that make contact with the DIN rail when the controller is placed on the DIN rail.




Figure 4-1 Placing the module **vertically**

4.2 Basic information

Mounting location The controller meets the requirements for the IP20 degree of protection. Due to its compact design, the controller can be installed in standard terminal boxes.

Mounting/DIN rail The controller is mounted on a 35 mm standard DIN rail without any tools using the bus base module. It is mounted perpendicular to the DIN rail. The local bus is created automatically when the bus base modules of the controller and Axioline F devices are installed next to one another.



Observe the notes on securing the DIN rail and fastening elements as well as the notes on mounting distances in the UM EN AXL F SYS INST user manual.

Supply connector The controller has a supply connector for connecting the power supply. The connector is fitted with spring-cage terminal blocks. When using suitable conductors, the conductors can be connected by means of direct connection technology (Push-in technology).



For additional information, please refer to [Section 5.1.2](#).

FE connection There are two FE springs (metal contacts) on the bottom of the controller which establish the connection to functional ground when the controller is snapped onto a grounded DIN rail.

End brackets Mount end brackets on both sides of the Axioline F station. The end brackets ensure that the Axioline F station is correctly mounted. End brackets secure the station on both sides and keep it from moving from side to side on the DIN rail. Phoenix Contact recommends the following end brackets:

Table 4-1 Recommended end brackets

Mounting position	Ambient conditions	End bracket
Horizontal; A in Figure 4-2 on page 47 :	Normal	CLIPFIX 35, CLIPFIX 35-5
	High shock and vibration load	E/AL-NS 35
Other; B in Figure 4-2 on page 47	Normal	E/AL-NS 35
	High shock and vibration load	

Mounting position

As standard, mount the controller in a horizontal position on the DIN rail provided for that purpose (A in [Figure 4-2](#)).




Figure 4-2 Example: AXCF 2152 in horizontal (A) and vertical (B) installation position

Note the ambient temperatures and any other special features (e.g., derating) specified in the device/module-specific documentation for the Axioline F devices.

4.3 Structure of an Axioline F station

Figure 4-3 shows an example structure of an Axioline F station with the AXC F 2152:




Figure 4-3 Example: Structure of an Axioline F station with the AXC F 2152

Key:

- 1 DIN rail
- 2 End bracket (e.g., CLIPFIX 35-5; Order No. 3022276)
- 3 Controller
- 4 I/O modules (Axioline F devices) corresponding to the application
- 5 Bus base module

An Axioline F station is set up by mounting the individual components side by side. No tools are required. Mounting the components side by side automatically creates potential and bus signal connections between the individual components of the Axioline F station.

Left-alignment of Axioline F extension modules



For additional information on the number and order of left-alignable Axioline F extension modules, refer to [page 15](#).

Figure 4-4 shows an example structure of an Axioline F station with the AXC F 3152 controller and the left-aligned Axioline F AXC F XT IB extension module:




Figure 4-4 Example: Axioline F station with AXC F 3152 and left-aligned Axioline F extension module

Key:

- 1 DIN rail
- 2 End bracket (e.g., CLIPFIX 35-5; Order No. 3022276)
- 3 Left-alignable Axioline F AXC F XT IB extension module
- 4 AXC F 3152 controller
- 5 I/O modules (Axioline F devices) corresponding to the application
- 6 Bus base module

4.4 Structure of a PLCnext Inline station

As an alternative to an Axioline F station, you can create a PLCnext Inline station using the controller. To do so, you need the AXC F IL ADAPT Inline adapter terminal (Order No. 1020304). You can directly align the Inline modules to the Inline adapter terminal.




Figure 4-5 Example: Structure of a PLCnext Inline station with the AXC F 2152

- 1 End bracket (e.g., CLIPFIX 35-5, Order No. 3022276)
- 2 Controller
- 3 Inline adapter terminal
- 4 Inline terminals corresponding to the application
- 5 End plate (snapped onto the DIN rail as station end)



For mounting information, please refer to the packing slip and the data sheet for the Inline adapter terminal. The documents can be downloaded at phoenixcontact.com/product/1020304.



Various function blocks are available in PLCnext Engineer for INTERBUS configuration and communication. For more detailed information, please refer to the PLCnext Engineer online help. For more detailed information on PCP and INTERBUS services, please refer to the following user manuals: "Peripherals Communication Protocol (PCP)" (IBS SYS PCP G4 UM E), "Firmware Services and Error Messages" (IBS SYS FW G4 UM E), and "For diagnostics in Generation 4 controller boards" (IBS SYS DIAG DSC UM E). The documents can be downloaded at phoenixcontact.com/product/1020304.

4.5 Mounting the controller

- Disconnect the Axioline F station from the power supply.
- Mount the left end bracket on the Axioline F station.

Mounting bus base modules

- First install the bus base module for the controller and then all bus base modules necessary for the Axioline F station on the DIN rail (A in [Figure 4-6](#)).
- Push each subsequent bus base module into the connection of the previous bus base module (B in [Figure 4-6](#)).




Figure 4-6 Mounting the bus base modules

Snapping the controller into place

- Push the controller vertically onto the first bus base module until it snaps into place with a click.
- Make sure that the device plug for the bus base connection is situated above the corresponding socket on the bus base module.




Figure 4-7 Snapping the controller into place

4.6 Inserting the SD card



NOTE: Damage to the SD card after formatting

The SD card is already formatted (ext4 format) and is intended for use with Phoenix Contact controllers of the PLCnext Control product family. If you format the SD card, certain information on the SD card that is required for use with Phoenix Contact devices will be lost. After formatting, you can no longer use the SD card to operate the controller.

- Ensure that the SD card is not formatted.
- If you want to delete the overlay file system from the SD card:
Reset the controller to default setting type 1.



The SD card will be recognized during the initialization phase of the controller. If you insert the SD card during operation, the SD card will not be recognized.

- Make sure that the SD card has been inserted before switching on the controller, in order to enable the controller to use it.
- Insert and remove the SD card only when the controller supply voltage is disconnected.
Refer to [Section “Diagnostic and status indicators” on page 29](#) for the LED blink codes in the event of unauthorized removal of the SD card during operation.
- Only use an SD card provided by Phoenix Contact, see [Section “Ordering data and technical data” on page 78](#).



The SD card is optional and not supplied as standard with the controller.

Please refer to the ordering data in [Section “Ordering data and technical data” on page 78](#).

- Disconnect the Axioline F station from the power supply.

The controller has an SD card holder with push/push technology.

- On the AXC F 1152 and AXC F 2152, remove the upper marking field of the controller (item 1 in [Figure 4-8](#)).




Figure 4-8 Removing the upper marking field of the AXC F 1152 and AXC F 2152

- Gently push the SD card into the SD card holder until it engages with a click in the SD card holder (see [Figure 4-9](#), “Click”).




Figure 4-9 Inserting the SD card

4.7 Mounting a left-alignable Axioline F extension module

- Mount the left-alignable Axioline F extension module as described in the module-specific packing slip and module-specific data sheet.



For additional information on the number and order of left-alignable Axioline F extension modules, refer to [page 15](#).

4.8 Mounting the AXC F IL ADAPT Inline adapter terminal

- Mount the Inline adapter terminal as described in the module-specific packing slip and module-specific data sheet.

5 Connecting and wiring hardware

5.1 Supply voltage

5.1.1 Sizing of the power supply

- Choose a power supply unit that is suitable for the currents in your application. The selection depends on the bus configuration and the resulting maximum currents.



WARNING: Loss of electrical safety when using unsuitable power supplies

The controllers are designed exclusively for operation with protective extra-low voltage (PELV) in accordance with EN 60204-1. Only PELV in accordance with the listed standard may be used for the supply.

The following applies to the network (PROFINET and Axioline F) and the I/O devices used in it:

Only use power supply units that meet EN 61204-1, with safe isolation and PELV in accordance with IEC 61010-2-201 (PELV). These prevent short circuits between primary and secondary sides.



A power supply without a fall-back characteristic curve must be used for the correct operation of the controller (see Figure 5-2).

When the controller is switched on, an increased inrush current occurs briefly. When it is switched on, the controller behaves like a capacitive load.

Some electronically controlled power supplies have a fall-back characteristic curve (see Figure 5-1). They are not suitable for operation with capacitive loads.




Figure 5-1 Overload range **with** fall-back characteristic curve




Figure 5-2 Overload range **without** fall-back characteristic curve

5.1.2 Connecting the power supply

Observe the notes in [Section 3.16](#) when assembling the connector for the supply voltage.

- Strip 8 mm off the cable. If necessary, fit a ferrule to the cable.



When using ferrules:

- Use ferrules in accordance with the specifications in the UM EN AXL F SYS INST user manual.
- Make sure that the ferrules are crimped correctly.

Rigid conductor/ferrule

- Insert the conductor into the terminal point. It is clamped into place automatically.




Figure 5-3 Connecting a rigid conductor

Flexible conductor

- Open the spring by pressing on the spring lever with a screwdriver (A in [Figure 5-4](#)).
- Insert the conductor into the terminal point (B in [Figure 5-4](#)).
- Remove the screwdriver to secure the conductor (recommended: bladed screwdriver, blade width 2.5 mm (e.g., SZS 0,4 x 2,5 VDE, Order No. 1205037))






Figure 5-4 Connecting a flexible conductor

Connecting the supply connector

- Place the supply connector vertically into its position and press down firmly. Make sure that the locking latch snaps into place.



AXC F 1152 and AXC F 2152



AXC F 3152

Figure 5-5 Connecting the supply connector

Supply the controller via external 24 V DC sources. The permissible voltage range is 19.2 V DC to 30 V DC (ripple included).



Only use power supplies that are suitable for operation with capacitive loads (increased inrush current) (see [Section 5.1.1](#)).

1. Connect the power supplies to the supply connector as shown in [Figure 5-3](#) and in [Figure 5-4](#). Note the information in [Section 3.16](#).
2. Switch on the power supplies.

The controller is now fully initialized.

If the LEDs do not light up or start flashing, there is a serious fault in the controller. In this case, please contact Phoenix Contact.



Please note the following when using left-alignable Axioline F extension modules:
The supply voltage of the controller and the left-alignable Axioline F extension modules must be fed in via a **shared** power supply unit.

- Connect the supply voltage as described in the module-specific data sheet.

5.2 Connecting Ethernet

- Connect the Ethernet network to the RJ45 jack.




Figure 5-6 Connecting Ethernet

6 Startup

The PLCnext Engineer software is required for starting up the controllers.



In addition, the following topics are available in the [PLCnext Info Center](#):

- Configuring Axioline F modules
- Configuring Inline modules
- Adding left-alignable Axioline F extension modules to the bus configuration
- Configuring PROFINET devices
- Programming according to IEC 61131-3
- Instantiating of programs
- Assigning process data
- Specifying the refresh interval for Axioline F I/O data
- Transferring a project to the controller
- Creating a PLCnext Engineer HMI application

6.1 Installing PLCnext Engineer

The software can be downloaded at phoenixcontact.com/product/1046008.

- Download the software onto your PC.
- Double-click the *.exe file to start installation.
- Follow the instructions in the installation wizard.

Make sure you install a version of the PLCnext Engineer software that is suitable for your controller:

Controller	PLCnext Engineer version
AXC F 1152	≥2020.0
AXC F 2152	≥2020.0
AXC F 3152	≥2020.3

6.2 User interface




Figure 6-1 PLCnext Engineer user interface

1. Menu bar
2. Tool bar
3. “PLANT” area
4. Editors area
5. “COMPONENTS” area
6. Cross-functional area
7. Status bar

“PLANT” area

All of the physical and logical components of your application are mapped in the form of a hierarchical tree structure in the “PLANT” area.

Editors area

Double-clicking on a node in the “PLANT” area or an element in the “COMPONENTS” area opens the associated editor group in the Editors area. Editor groups are always displayed in the center of the user interface. The color of the editor group indicates whether it is an instance editor (green; opened from the “PLANT” area) or a type editor (blue; opened from the “COMPONENTS” area). Each editor group contains several editors that can be opened and closed via buttons in the editor group.

“COMPONENTS” area

The “COMPONENTS” area contains all of the components available for the project. The components can be divided into the following types based on their function:

- Developing program code (“Data Types”, “Programs”, and “Functions & Function Blocks”)
- Displaying all devices available for the “PLANT” area and adding them via GSDML or FDCML (“Devices”)
- Editing HMI pages (“HMI”)

- Adding libraries such as firmware libraries, IEC user libraries or libraries provided by Phoenix Contact (“References”)

Cross-functional area

The cross-functional area contains functions that extend across the entire project.

- **ERROR LIST:**
Shows all errors, warnings, and messages for the current project.
- **GLOBAL FIND AND REPLACE:**
Finds and replaces strings in the project.
- **CROSS REFERENCES:**
Displays all cross-references within the project, for example, the use and declaration of all variable types or HMI tags.
- **WATCH WINDOWS:**
Debug tool; shows the current values of the added variables in online mode.
- **BREAKPOINTS:**
Debug tool for setting and resetting breakpoints when debugging within the application.
- **CALL STACKS:**
Debug tool that shows the order for calling up when executing the code and that contains commands for debugging with breakpoints.
- **LOGIC ANALYSIS:**
Records and visualizes variable values at runtime.
- **LOGGING:**
Shows all errors, warnings, and messages. A distinction is made between “online” (messages regarding the runtime environment, as well as errors and warnings that concern online communication) and “engineering” (messages regarding software events, e.g., GSDML and FDCML files; not project-related).
- **RECYCLE BIN:**
Elements that have recently been deleted from the “PLANT” or “COMPONENTS” areas are moved to the recycle bin. Deleted elements can be restored from here, if needed.

6.3 Creating a new project

- Open PLCnext Engineer.
- On the start page, click on a project template, e.g., “Empty AXC F 2152 v00 / 2020.0.0 project”.

The project template for an empty AXC F 2152 project opens.




Figure 6-2 Start page, “Empty AXC F 2152 v.00 / 2020.0.0 project” project template

- Open the “File, Save Project As...” menu.
- Enter a unique and meaningful name for the project.
- Click on “Save”.

6.4 Configuring the IP settings

6.4.1 Setting the IP address range

- Double-click the “Project (x)” node in the “PLANT” area.

The “Project” editor group opens.

- Select the “Settings” editor.
- Set the desired IP address range and the subnet mask for the project.




Figure 6-3 Setting the IP address range

6.4.2 Setting the IP address

- Double-click the controller node in the “PLANT” area.

The controller editor group opens.

- Select the “Settings” editor.
- Select the “Ethernet” view.




Figure 6-4 Setting the IP address

The IP address of the controller can be set automatically or manually. The IP address is assigned to the controller when you have connected PLCnext Engineer to the controller, see [Section 6.5](#).

Setting the IP address automatically

- From the “IP address assignment mode” drop-down list, select “automatic”.

PLCnext Engineer automatically assigns an IP address to the controller from the set IP address range (see [Section 6.4.1, “Setting the IP address range”](#)) as soon as a connection to the controller is established (see [Section 6.5](#)).

Setting the IP address manually

- From the “IP address assignment mode” drop-down list, select “manual”.
- Enter the IP address, subnet mask, and gateway in the respective input fields.

PLCnext Engineer assigns the manually set IP address to the controller as soon as a connection to the controller is established (see [Section 6.5](#)).



If you are using an SD card, the IP address will be stored there. In the event of a device replacement, the IP address will then be adopted by the new controller when the SD card is inserted.

6.5 Connecting to the controller

To be able to transfer a project to the controller, you must first connect PLCnext Engineer to the controller. To do this, proceed as follows:

- Double-click the “Project (x)” node in the “PLANT” area.

The “Project” editor group opens.

- Select the “Online Devices” editor.
- Select the appropriate network card from the drop-down list.



Figure 6-5 Selecting the network card



You can show and hide more detailed information by clicking on the arrows next to “Name of station (Project)” and “Name of station (Online)” (see [Figure 6-5](#)).

- Click on the button to search the network for connected devices.

You can see the configured devices under “Name of station (Project)”.

You can see the devices that have been found online in the network (online devices) under “Name of station (Online)”.




Figure 6-6 Assigning online devices

If you select the device (“Select online device here”) under “Name of station (Online)”, the controller found in the network (the online device) receives the IP settings of the configured controller.

If you select the device (“Select project device here”) under “Name of station (Project)”, the configured controller receives the IP settings of the online device found in the network.

- Select the desired device.

The configured controller has now been assigned to an online device.



If the IP address of an online device found in the network already matches the IP address of the configured controller, the online device is automatically assigned to the configured controller. In this case, you do not need to select the desired device for the assignment.

The icon in the “Status” column indicates that the assignment was successful.



Figure 6-7 Successful assignment of the configured controller to an online device

Once the configured controller has been assigned to an online device, you can connect PLCnext Engineer to the controller:

- Double-click the controller node in the “PLANT” area.

The controller editor group opens.

- Select the “Cockpit” editor.
- Click on the button to connect PLCnext Engineer to the controller.

The “SECURE DEVICE LOGIN” dialog opens.





Figure 6-8 “SECURE DEVICE LOGIN” dialog

- Enter your user name and your password.

In the delivery state, the following access data with administrator rights is preset:

User name: admin

Password: printed on the controller (see [Figure 3-8](#) and [Figure 3-9](#)).

The  icon next to the controller node in the “PLANT” area indicates that connection was successful.




Figure 6-9 Successful connection to the controller



For additional information, please refer to the PLCnext Info Center and the PLCnext Engineer online help.

7 PROFICLOUD.IO

The Proficloud offers an easy way of managing remote PLCnext devices. The main functions are:

- Device Management Service:
 - Showing a device overview with exact geolocation of all connected devices
 - Showing the status of all connected devices
 - Showing key information for all connected devices
 - Reporting logs from the connected devices
 - Checking for firmware updates and updating connected devices
- Time-series data service:
 - Storing variable values in the Proficloud



You can find more information about the Proficloud in the [PLCnext Info Center](#).

8 System variables and status information



A detailed description of the system variables available for the controllers can be found in the [PLCnext Info Center](#).

The controller has a register set that is used for diagnostics and easy control of the controller and the Axioline F local bus.

The diagnostic data is stored in the diagnostic status register and the diagnostic parameter register. These registers are available to the application program as system variables (system flags, global variables).

In the PLCnext Info Center you will find detailed descriptions of the system variables of the following areas:

- System time
- Power supplies
- TCP_SOCKET, UDP_SOCKET, and TLS_SOCKET function blocks
- Device status
- Partition
- Task handling
- HMI status and control
- Axioline F: Diagnostic status and diagnostic parameter register
- PROFINET system variables
- INTERBUS: master diagnostic status and parameter register

9 Web-based management (WBM)

In the web-based management (WBM) system, you can access static and dynamic controller information and modify certain controller settings. The WBM can be called up via any of the controller's Ethernet interfaces.



For a description of the web-based management, refer to the [PLCnext Info Center](#). There you will find information on the following topics:

- Information, e.g. general data and network configuration
- Diagnostics, e.g. network, PROFINET, notifications, local bus
- Configuration, e.g. PROFICLOUD services, web and system services, network
- Security, e.g. user authentication, certificates, LDAP, firewall, SD cards
- Administration, e.g. firmware update, licenses, apps

10 Removing hardware



For basic information on the Axioline F system and its installation, particularly mounting/removing Axioline F modules, please refer to the UM EN AXL F SYS INST user manual (“Axioline F: system and installation”).

10.1 Safety notes



NOTE: Electrostatic discharge

The device contains components that can be damaged or destroyed by electrostatic discharge. When handling the device, observe the necessary safety precautions against electrostatic discharge (ESD) in accordance with EN 61340-5-1 and IEC 61340-5-1.



NOTE: Damage to electronics due to inadequate external protection – no safe fuse tripping in the event of a fault

The electronics in the device will be damaged if external fuse protection is inadequate.

- Protect the supply voltage externally in accordance with the connected load (number of Axioline F devices/amount of logic current consumption for each device).
- Ensure that the external fuse trips reliably in the event of a fault.



NOTE: Damage to the contacts when tilting

Tilting the modules can damage the contacts.

- Remove the modules **vertically** from the DIN rail.



Please note:

- During any work on the Axioline F station, the controller or a module, switch off the power supply to the Axioline F station and make sure the supply voltage is protected against unauthorized reactivation.




Figure 10-1 Removing the module **vertically**

10.2 Removing cables

- Disconnect the Axioline F station from the power supply.

The cables should only be removed from the supply connector if you wish to change the terminal point assignment or no longer wish to use the supply connector.

- Open the spring by pressing on the spring lever with a screwdriver (A in [Figure 10-2](#)).
- Remove the cable (B in [Figure 10-2](#)).





Figure 10-2 Removing the cable

10.3 Removing the connector

Removing the supply connector

- Release the locking latch (A in [Figure 10-3](#)), tilt the connector upwards slightly (B in [Figure 10-3](#)), and remove it from the controller (C in [Figure 10-3](#)).



AXC F 1152 and AXC F 2152

AXC F 3152


Figure 10-3 Removing the supply connector

Removing the Ethernet connector


- Release the RJ45 connector by pressing on the snap-in latch and remove the connector.

10.4 Removing the SD card

- Lightly push the SD card far enough into the SD card holder until the snap-in mechanism releases the SD card and partially ejects the SD card from the SD card holder.
- Remove the SD card.



AXC F 1152 and AXC F 2152



AXC F 3152

Figure 10-4 Removing the SD card

10.5 Removing the controller

- Insert a suitable tool (e.g., bladed screwdriver) into the upper and lower snap-in mechanisms (base latches) of the controller one after the other and release the controller (A in Figure 10-5).

The base latches are locked in place in the open position.

- Remove the controller keeping it perpendicular to the DIN rail (B in Figure 10-5).




Figure 10-5 Removing the controller

10.6 Removing a left-alignable Axioline F extension module

- Remove the left-alignable Axioline F extension module as described in the module-specific packing slip.

10.7 Removing the AXC F IL ADAPT Inline adapter terminal

- Remove the Inline adapter terminal as described in the module-specific packing slip.

11 Device replacement, device defects, and repairs

11.1 Device replacement

The controller can be replaced, if necessary.

If you want to replace a controller in an Axioline F station, follow the steps described in [Section 10, "Removing hardware"](#) and [Section 4, "Mounting hardware"](#).

- Disconnect the Axioline F station from the power supply.
- Remove the SD card of the controller to be replaced.
- Replace the controller in your application with an identical controller (same order number).

**Please note:**

If the new controller firmware is of a later version than the firmware of the controller to be replaced, you may have to recompile the project in the PLCnext Engineer software and/or in the integrated development environment. This procedure is only necessary for certain firmware versions. For additional information, please refer to the "Change notes for the controller" application note.

The application note can be downloaded at phoenixcontact.com/product/2404267.

- To adopt the settings stored on the SD card, insert the SD card into the new controller.
- Once the controller is replaced, restore all the necessary connections.

In case you operate the controller with PROFICLOUD connection:

- Delete the controller from PROFICLOUD.
- Then reregister the controller in PROFICLOUD and add it as a PROFICLOUD device, as described in [Section "PROFICLOUD.IO" on page 67](#).

11.2 Device defects and repair

Repairs may only be carried out by Phoenix Contact.

- Send defective devices back to Phoenix Contact for repair or to receive a replacement device.
- We strongly recommend using the original packaging to return the product.
- Include a note in the packaging indicating that the contents are returned goods.
- If the original packaging is no longer available, observe the following points:
 - Observe the humidity specifications and the temperature range specified for transport (see [Section 14](#)).
 - If necessary, use dehumidifying agents.
 - Use suitable ESD packaging to protect components that are sensitive to electrostatic discharge.
 - Secure any loose parts.
 - Make sure that the packaging you select is large enough and that the material used is sufficiently thick.
 - Only use plastic bubble wrap sheets as wadding.
 - Attach warnings to the transport packaging so that they are clearly visible.
 - Please ensure that the delivery note is placed inside the package if the package is to be shipped domestically. However, if the package is being shipped internationally, the delivery note must be placed inside a delivery note pocket and attached to the outside so that it is clearly visible.

12 Maintenance, decommissioning, and disposal

12.1 Maintenance

The controller is maintenance-free.

12.2 Decommissioning and disposal

Controller disposal



The symbol with the crossed-out trash can indicates that this item must be collected and disposed of separately from other waste. Phoenix Contact or public collection sites will take the item back for free disposal. For information on the available disposal options, visit phoenixcontact.com. Delete personal data before returning the item.

Packaging disposal

- Dispose of packaging materials that are no longer needed (cardboard packaging, paper, bubble wrap sheets, etc.) with household waste in accordance with the currently applicable national regulations.

SD card disposal

Sensitive data is stored on the SD card. This data can even be restored after reformatting the SD card. To ensure that your data does not fall into unauthorized hands, you should physically destroy the SD card before disposal.

- Physically destroy the SD card, e.g., by cutting up the SD card.
- Dispose of the irreparably damaged SD card in accordance with the applicable national regulations.

13 Troubleshooting and frequently asked questions (FAQs)



Information on troubleshooting and answers to frequently asked questions (FAQs) can be found in the PLCnext Community at plcnext-community.net.

14 Ordering data and technical data

14.1 AXC F 1152

14.1.1 Ordering data

Description	Type	Item no.	Pcs./Pkt.
PLCnext Control for the direct control of Axioline F I/Os. With two Ethernet interfaces. Complete with connector and bus base module.	AXC F 1152	1151412	1

Accessories


For accessories, go to: www.phoenixcontact.com/product/1151412

Documentation

For further documentation, go to: www.phoenixcontact.com/product/1151412

14.1.2 Technical data

Dimensions (nominal sizes in mm)



Width	45 mm
Height	126.93 mm
Depth	75 mm
Note on dimensions	The depth is valid when a TH 35-7,5 DIN rail is used (according to EN 60715).

General data	
Color	Housing: traffic grey A (RAL 7042)
Weight	223 g (with connector and bus base module)
Type	modular
Mounting type	DIN rail mounting
Module classification	PLCnext Control for direct control of Axioline F I/Os
Application type	Distributed control technology
Operating system	Yocto/Linux
Processor	Arm® Cortex®-A9 1x 800 MHz
RAM	512 Mbyte DDR3 SDRAM
Flash memory	512 Mbyte (internal flash memory) SD card from Phoenix Contact (for external flash memory, see accessories)
Application interface	OPC UA
Realtime clock	Yes
External memory	Yes
Web server	Yes
Diagnostics display	No
Controller redundancy	No
Safety function	No
Optical interface	No
Ambient conditions	
Ambient temperature (operation)	-25 °C ... 60 °C up to 2000 m above mean sea level (observe derating) -25 °C ... 55 °C up to 3000 m above mean sea level (observe derating) ≤ 55 °C (with max. 1 A on U _{Bus}) > 55 °C ... 60 °C (only in conjunction with an Axioline F power module AXL F PWR 1H (Item no. 2688297))
Ambient temperature (storage/transport)	-40 °C ... 85 °C
Permissible humidity (operation)	5 % ... 95 % (according to DIN EN 61131-2)
Permissible humidity (storage/transport)	5 % ... 95 % (according to DIN EN 61131-2)
Air pressure (operation)	70 kPa ... 106 kPa (up to 3000 m above sea level)
Air pressure (storage/transport)	58 kPa ... 106 kPa (up to 4500 m above mean sea level)
Degree of protection	IP20
Protection class	III (IEC 61140, EN 61140, VDE 0140-1)
Overvoltage category	II
Vibration (operation)	5g (according to EN 60068-2-6/IEC 60068-2-6)
Shock (operation)	30g (according to EN 60068-2-27/IEC 60068-2-27)
Continuous shock (operation)	10g (according to EN 60068-2-27/IEC 60068-2-27)

Connection data	
Designation	Axioline F connector
Connection method	Push-in connection
Conductor cross section solid / stranded	0.2 mm ² ... 1.5 mm ²
Conductor cross section [AWG]	24 ... 16
Stripping length	8 mm

Interface Axioline F local bus	
Connection method	Bus base module
Number of interfaces	1
Transmission speed	100 Mbps
Electrical isolation	No
Number of supported devices	max. 63

Interface Ethernet	
Bus system	RJ45
Connection method	RJ45 jack
Note on the connection method	Auto negotiation and autocrossing
Number of interfaces	2 (switched internally)
Transmission speed	10/100 Mbps (full duplex)
Transmission length	max. 100 m
Transmission physics	Ethernet in RJ45 twisted pair
Protocols supported	HTTP HTTPS SFTP SNTP SNMP IPsec syslog OPC UA

System limits	
Amount of process data	max. 1482 Byte (per station (total input and output data)) max. 1024 Byte (Axioline F local bus (input)) max. 1024 Byte (Axioline F local bus (output))
Number of supported devices	max. 63 (per station)
Number of local bus devices that can be connected	max. 63 (observe current consumption)
Number of IO-Link masters	max. 8 (recommended)



NOTE: Electronics may be damaged when overloaded

Observe the logic current consumption of each device when configuring an Axioline F station. It is specified in every module-specific data sheet. The current consumption can differ depending on the individual module. The permissible number of devices that can be connected therefore depends on the specific station structure.

PROFINET

Device function	PROFINET controller, PROFINET device
Number of supported devices	max. 16 (at PROFINET controller)
Specification	Version 2.3
Conformance Class	A
Update rate	min. 1 ms (4 devices) min. 4 ms (16 devices)
Number of slots	1
Vendor ID	00B0 _{hex}
Device ID	0169 _{hex}
Process data width	64 Byte ... 512 Byte (PROFINET device)
Supported functions	MRP, FSU (PROFINET controller), MRP (PROFINET device)

Communications power U_L feed-in (the supply of the Axioline F local bus U_{BUS} is generated from U_L)

Supply voltage	24 V DC
Supply voltage range	19.2 V DC ... 30 V DC (including all tolerances, including ripple ($\pm 5\%$))
Current consumption	typ. 200 mA (without I/Os and $U_L = 24$ V) max. 442 mA (with 1 A at U_{BUS} for the I/Os and $U_L = 24$ V)
Power consumption	typ. 4.8 W (without I/Os) max. 10.6 W (with 1 A at U_{BUS} for the I/Os and $U_L = 24$ V)
Surge protection	electronic
Reverse polarity protection	electronic

**NOTE: Electronics may be damaged when overloaded**

Provide external fuses for the 24 V U_L area. If you are using an external fuse, the power supply unit must be able to supply four times the nominal current of the fuse. This ensures that it trips in the event of an error.

Axioline F local bus supply (U_{BUS})

Supply voltage	5 V DC (via bus base module)
Power supply unit	1 A

Realtime clock

Accuracy realtime clock	1.73 s/day = 20 ppm at 25 °C
Power reserve	240 h (at 25 °C)

Programming Data

Register length (master)	1482 Byte
--------------------------	-----------

Programming

Programming tool	PLCnext Engineer Eclipse Visual Studio MATLAB® Simulink®
Programming languages supported	Instruction list (IL) Symbolic flowchart (SFC) Ladder diagram (LD) Function block diagram (FBD) Structured text (ST) C++ C# Java Python Simulink

IEC 61131 runtime system

Number of data blocks	depending on data storage
Number of control tasks	8
Cycle Time	5 ms (for cyclical task)
Program memory	8 Mbyte
Data storage	12 Mbyte
Retentive data storage	48 kByte (NVRAM)

Conformance with EMC Directive 2014/30/EU

Immunity test in accordance with EN 61000-6-2/IEC 61000-6-2

Electrostatic discharge (ESD) EN 61000-4-2/IEC 61000-4-2	Criterion B, 6 kV contact discharge, 8 kV air discharge
Electromagnetic fields EN 61000-4-3/IEC 61000-4-3	Criterion A, Field intensity: 10 V/m
Fast transients (burst) EN 61000-4-4/IEC 61000-4-4	Criterion B, 2 kV
Transient overvoltage (surge) EN 61000-4-5/IEC 61000-4-5	Criterion B, DC supply lines: ±0.5 kV/±0.5 kV (symmetrical/asymmetrical), fieldbus cable shield: ±1 kV
Conducted interference EN 61000-4-6/IEC 61000-4-6	Criterion A, Test voltage 10 V

Noise emission test in accordance with EN 61000-6-4/IEC 61000-6-4



NOTE: radio interference

This is a Class A item of equipment. When using the equipment in residential areas, it may cause radio interference. In this case, the operator may be required to implement appropriate measures and to pay the resulting costs.

Approvals

For the current approvals, go to:

www.phoenixcontact.com/product/1151412

Industrial Cyber Security (IITS2 029429 0027 Rev. 00)

Industrial IT Security, IACS Component

IEC 62443-4-1:2018

IEC 62443-4-2:2019

PPP 15003B:2021 (IEC 62443-4-1: Full ML3 Process Profile)

Configuration: Security Profile active

Manufacturer's declarations

For the current manufacturer's declarations, go to:

www.phoenixcontact.com/product/1151412

14.2 AXC F 2152

14.2.1 Ordering data

Description	Type	Item no.	Pcs./Pkt.
PLCnext Control for the direct control of Axioline F I/Os. With two Ethernet interfaces. Complete with connector and bus base module.	AXC F 2152	2404267	1

Accessories


For accessories, go to: www.phoenixcontact.com/product/2404267

Documentation

For further documentation, go to: www.phoenixcontact.com/product/2404267

14.2.2 Technical data

Dimensions (nominal sizes in mm)



Width	45 mm
Height	126.93 mm
Depth	75 mm
Note on dimensions	The depth is valid when a TH 35-7,5 DIN rail is used (according to EN 60715).

General data

Color	Housing: traffic grey A (RAL 7042)
Weight	223 g (with connector and bus base module)
Type	modular
Mounting type	DIN rail mounting

General data	
Module classification	PLCnext Control for direct control of Axioline F I/Os.
Application type	Distributed control technology
Operating system	Yocto/Linux
Processor	Arm® Cortex®-A9 2x 800 MHz
RAM	512 Mbyte DDR3 SDRAM
Flash memory	512 Mbyte (internal flash memory) SD card from Phoenix Contact (for external flash memory, see accessories)
Application interface	OPC UA
Realtime clock	Yes
Controller redundancy	Yes (applicative system redundancy possible)
External memory	Yes
Web server	Yes
Diagnostics display	No
Safety function	No
Optical interface	No

Ambient conditions	
Ambient temperature (operation)	-25 °C ... 60 °C up to 2000 m above mean sea level (observe derating) -25 °C ... 55 °C up to 3000 m above mean sea level (observe derating) ≤ 55 °C (with max. 1 A on U _{Bus}) > 55 °C ... 60 °C (only in conjunction with an Axioline F power module AXL F PWR 1H (Item no. 2688297))
Ambient temperature (storage/transport)	-40 °C ... 85 °C
Permissible humidity (operation)	5 % ... 95 % (according to DIN EN 61131-2)
Permissible humidity (storage/transport)	5 % ... 95 % (according to DIN EN 61131-2)
Air pressure (operation)	70 kPa ... 106 kPa (up to 3000 m above sea level)
Air pressure (storage/transport)	58 kPa ... 106 kPa (up to 4500 m above mean sea level)
Degree of protection	IP20
Protection class	III (IEC 61140, EN 61140, VDE 0140-1)
Overvoltage category	II
Pollution degree	2
Vibration (operation)	5g (according to EN 60068-2-6/IEC 60068-2-6)
Shock (operation)	30g (according to EN 60068-2-27/IEC 60068-2-27)
Continuous shock (operation)	10g (according to EN 60068-2-27/IEC 60068-2-27)

Connection data	
Designation	Axioline F connector
Connection method	Push-in connection
Conductor cross section solid / stranded	0.2 mm ² ... 1.5 mm ²
Conductor cross section [AWG]	24 ... 16
Stripping length	8 mm

Interface Axioline F local bus	
Connection method	Bus base module
Number of interfaces	1
Transmission speed	100 Mbps
Electrical isolation	No
Number of supported devices	max. 63

Interface Ethernet	
Bus system	RJ45
Connection method	RJ45 jack
Note on the connection method	Auto negotiation and autocrossing
Number of interfaces	2 (switched internally)
Transmission speed	10/100 Mbps (full duplex)
Transmission length	max. 100 m
Transmission physics	Ethernet in RJ45 twisted pair
Protocols supported	HTTP HTTPS SFTP SNTP IPsec syslog OPC UA

System limits	
Amount of process data	max. 1482 Byte (per station (total input and output data)) max. 1024 Byte (Axioline F local bus (input)) max. 1024 Byte (Axioline F local bus (output))
Number of supported devices	max. 63 (per station)
Number of local bus devices that can be connected	max. 63 (observe current consumption)
Number of IO-Link masters	max. 8 (recommended)



NOTE: Electronics may be damaged when overloaded

Observe the logic current consumption of each device when configuring an Axioline F station. It is specified in every module-specific data sheet. The current consumption can differ depending on the individual module. The permissible number of devices that can be connected therefore depends on the specific station structure.

PROFINET	
Device function	PROFINET controller, PROFINET device
Number of supported devices	max. 64 (at PROFINET controller)
Specification	Version 2.4
Conformance Class	B
Update rate	min. 1 ms (4 devices) min. 16 ms (64 devices)
Number of slots	1
Vendor ID	00B0 _{hex}

PROFINET

Device ID	0142 _{hex}
Process data width	512 Byte (PROFINET device)
Supported functions	MRP, FSU (PROFINET controller), MRP (PROFINET device)

Communications power U_L feed-in (the supply of the Axioline F local bus U_{BUS} is generated from U_L)

Supply voltage	24 V DC
Supply voltage range	19.2 V DC ... 30 V DC (including all tolerances, including ripple ($\pm 5\%$))
Current consumption	typ. 200 mA (without I/Os and $U_L = 24$ V) max. 442 mA (with 1 A at U_{BUS} for the I/Os and $U_L = 24$ V)
Power consumption	typ. 4.8 W (without I/Os) max. 10.6 W (with 1 A at U_{BUS} for the I/Os and $U_L = 24$ V)
Surge protection	electronic
Reverse polarity protection	electronic

**NOTE: Electronics may be damaged when overloaded**

Provide external fuses for the 24 V U_L area. If you are using an external fuse, the power supply unit must be able to supply four times the nominal current of the fuse. This ensures that it trips in the event of an error.

Axioline F local bus supply (U_{BUS})

Supply voltage	5 V DC (via bus base module)
Power supply unit	1 A

Realtime clock

Accuracy realtime clock	1.73 s/day = 20 ppm at 25 °C
Power reserve	240 h (at 25 °C)

Programming Data

Register length (master)	1482 Byte
--------------------------	-----------

Programming

Programming tool	PLCnext Engineer Eclipse Visual Studio MATLAB [®] Simulink [®]
Programming languages supported	Instruction list (IL) Symbolic flowchart (SFC) Ladder diagram (LD) Function block diagram (FBD) Structured text (ST) C++ C# Java Python Simulink

IEC 61131 runtime system

Number of data blocks	depending on data storage
Number of control tasks	32 (16 per processor core)
Cycle Time	1 ms (for cyclical task)
Program memory	8 Mbyte
Data storage	12 Mbyte
Retentive data storage	48 kByte (NVRAM)

Conformance with EMC Directive 2014/30/EU

Immunity test in accordance with EN 61000-6-2/IEC 61000-6-2

Electrostatic discharge (ESD) EN 61000-4-2/IEC 61000-4-2	Criterion B, 6 kV contact discharge, 8 kV air discharge
Electromagnetic fields EN 61000-4-3/IEC 61000-4-3	Criterion A, Field intensity: 10 V/m
Fast transients (burst) EN 61000-4-4/IEC 61000-4-4	Criterion B, 2 kV
Transient overvoltage (surge) EN 61000-4-5/IEC 61000-4-5	Criterion B, DC supply lines: ± 0.5 kV/ ± 0.5 kV (symmetrical/asymmetrical), fieldbus cable shield: ± 1 kV
Conducted interference EN 61000-4-6/IEC 61000-4-6	Criterion A, Test voltage 10 V

Noise emission test in accordance with EN 61000-6-4/IEC 61000-6-4



NOTE: radio interference

This is a Class A item of equipment. When using the equipment in residential areas, it may cause radio interference. In this case, the operator may be required to implement appropriate measures and to pay the resulting costs.

Approvals

For the current approvals, go to:	www.phoenixcontact.com/product/2404267
ATEX (TÜV 19 ATEX 8356 X)	Ⓜ II 3 G Ex ec IIC T4 Gc EN IEC 60079-0, EN IEC 60079-7
IECEX (IECEX TUR 19.0031X)	Ex ec IIC T4 Gc IEC 60079-0 Ed. 7, IEC 60079-7 Ed. 5.1
CCC / China-Ex (Ⓜ, 2021122304114448)	Ex ec IIC T4 Gc GB/T 3836.1-2021, GB/T 3836.3-2021
UL Ex, USA / Canada (E366272)	Class I, Zone 2, AEx nA IIC T4 Class I, Div. 2, Groups A, B, C, D Ex nA IIC Gc T4 UL 60079-0, Ed. 6 / CSA C22.2 NO. 60079-0, Ed. 3 UL 60079-15, Ed. 4 / CSA C22.2 NO. 60079-15
UL, USA/Canada (E238705)	cULus
Corrosive gas test	ISA S71.04.2013 G3 Harsh Group A, DIN EN 60068-2-60:2016-06 Method 4
Industrial Cyber Security (IITS2 029429 0027 Rev. 00)	Industrial IT Security, IACS Component IEC 62443-4-1:2018 IEC 62443-4-2:2019 PPP 15003B:2021 (IEC 62443-4-1: Full ML3 Process Profile) Configuration: Security Profile active

Manufacturer's declarations

For the current manufacturer's declarations, go to: www.phoenixcontact.com/product/2404267

UL: Additional information

Overvoltage category	2
Pollution degree	2
Operating mode	Indoor use
Minimum temperature rating and size of the cables to be connected to the field wiring terminals	min. 75 °C and 24 ... 16 AWG



- All types are intended to be used in final safety enclosure, which shall conform with requirements for protection against the spread of fire and shall have adequate rigidity acc. to UL 61010-1 & UL 61010-2-201.
- If the device is used in not specified manner, the protection provided by the device may be impaired.
- The supply source and ext. circuits intended to be connected to this device shall be galv. separated from mains supply or hazardous live voltage by reinforced or double insulation and meet the requirements of SELV circuit of UL/IEC 61010-2-201 and clause 9.4 Limited energy circuit of UL/IEC 61010-1 or NEC Class 2.

14.3 AXC F 3152

14.3.1 Ordering data


Description	Type	Item no.	Pcs./Pkt.
PLCnext Control for the direct control of AxioLine F I/Os. With three independent Ethernet interfaces. Complete with connector and bus base module.	AXC F 3152	1069208	1

Accessories
For accessories, go to: www.phoenixcontact.com/product/1069208

Documentation
For further documentation, go to: www.phoenixcontact.com/product/1069208

14.3.2 Technical data

Dimensions (nominal sizes in mm)



Width	100 mm
Height	126.93 mm
Depth	75 mm
Note on dimensions	The depth is valid when a TH 35-7,5 DIN rail is used (according to EN 60715).

General data	
Color	Housing: traffic grey A (RAL 7042)
Weight	498 g (with connector and bus base module)
Type	modular
Mounting type	DIN rail mounting
Module classification	PLCnext Control for direct control of Axioline F I/Os.
Application type	Distributed control technology
Operating system	Yocto/Linux
Processor	Intel® Atom™ x5-E3930 2x 1.3 GHz
RAM	2048 Mbyte
Flash memory	1 GByte (internal flash memory) SD card from Phoenix Contact (for external flash memory, see accessories)
Application interface	OPC UA
Realtime clock	Yes
Controller redundancy	Yes (applicative system redundancy possible)
External memory	Yes
Web server	Yes
Diagnostics display	No
Safety function	No
Optical interface	No

Ambient conditions	
Ambient temperature (operation)	-25 °C ... 60 °C up to 2000 m above mean sea level (observe derating) -25 °C ... 55 °C up to 3000 m above mean sea level (observe derating) ≤ 55 °C (with max. 1 A on U _{Bus}) > 55 °C ... 60 °C (only in conjunction with an Axioline F power module AXL F PWR 1H (Item no. 2688297))
Ambient temperature (storage/transport)	-40 °C ... 85 °C
Permissible humidity (operation)	5 % ... 95 % (according to DIN EN 61131-2)
Permissible humidity (storage/transport)	5 % ... 95 % (according to DIN EN 61131-2)
Air pressure (operation)	70 kPa ... 106 kPa (up to 3000 m above sea level)
Air pressure (storage/transport)	58 kPa ... 106 kPa (up to 4500 m above mean sea level)
Degree of protection	IP20
Protection class	III (IEC 61140, EN 61140, VDE 0140-1)
Overvoltage category	II
Pollution degree	2
Vibration (operation)	5g (according to EN 60068-2-6/IEC 60068-2-6)
Shock (operation)	30g (according to EN 60068-2-27/IEC 60068-2-27)
Continuous shock (operation)	10g (according to EN 60068-2-27/IEC 60068-2-27)

Connection data	
Designation	Axioline F connector
Connection method	Push-in connection
Conductor cross section solid / stranded	0.2 mm ² ... 1.5 mm ²
Conductor cross section [AWG]	24 ... 16
Stripping length	8 mm

Interface Axioline F local bus	
Connection method	Bus base module
Number of interfaces	1
Transmission speed	100 Mbps
Electrical isolation	No
Number of supported devices	max. 63

Interface Ethernet	
Bus system	RJ45
Connection method	RJ45 jack
Note on the connection method	Auto negotiation and autocrossing
Number of interfaces	3
Transmission speed	10/100/1000 Mbps
Transmission length	max. 100 m
Transmission physics	Ethernet in RJ45 twisted pair
Protocols supported	HTTP HTTPS SFTP SNTP SNMP IPsec syslog OPC UA

System limits	
Amount of process data	max. 1482 Byte (per station (total input and output data)) max. 1024 Byte (Axioline F local bus (input)) max. 1024 Byte (Axioline F local bus (output))
Number of supported devices	max. 63 (per station)
Number of local bus devices that can be connected	max. 63 (observe current consumption)
Number of IO-Link masters	max. 8 (recommended)



NOTE: Electronics may be damaged when overloaded

Observe the logic current consumption of each device when configuring an Axioline F station. It is specified in every module-specific data sheet. The current consumption can differ depending on the individual module. The permissible number of devices that can be connected therefore depends on the specific station structure.

PROFINET

Device function	PROFINET controller, PROFINET device
Number of supported devices	max. 128 (at PROFINET controller)
Specification	Version 2.4
Conformance Class	B
Update rate	min. 1 ms (32 participants) min. 2 ms (64 devices) min. 4 ms (128 participants)
Number of slots	1
Vendor ID	00B0 _{hex}
Device ID	0158 _{hex}
Process data width	64 Byte ... 512 Byte
Supported functions	FSU (PROFINET controller)

Communications power U_L feed-in (the supply of the Axioline F local bus U_{BUS} is generated from U_L)

Supply voltage	24 V DC
Supply voltage range	19.2 V DC ... 30 V DC (including all tolerances, including ripple ($\pm 5\%$))
Current consumption	typ. 260 mA (without I/Os and $U_L = 24$ V) max. 504 mA (with 1 A at U_{BUS} for the I/Os and $U_L = 24$ V)
Power consumption	typ. 6.24 W (without I/Os) max. 12.1 W (with 1 A at U_{BUS} for the I/Os and $U_L = 24$ V)
Surge protection	electronic
Reverse polarity protection	electronic

**NOTE: Electronics may be damaged when overloaded**

Provide external fuses for the 24 V U_L area. If you are using an external fuse, the power supply unit must be able to supply four times the nominal current of the fuse. This ensures that it trips in the event of an error.

Axioline F local bus supply (U_{BUS})

Supply voltage	5 V DC (via bus base module)
Power supply unit	1 A

Realtime clock

Accuracy realtime clock	0.7 s/day = 8 ppm at 25 °C
Power reserve	336 h (at 25 °C)

Programming Data

Register length (master)	1482 Byte
--------------------------	-----------

Programming	
Programming tool	PLCnext Engineer Eclipse Visual Studio MATLAB® Simulink®
Programming languages supported	Instruction list (IL) Symbolic flowchart (SFC) Ladder diagram (LD) Function block diagram (FBD) Structured text (ST) C++ C# Java Python Simulink
IEC 61131 runtime system	
Number of data blocks	depending on data storage
Number of control tasks	32 (16 per processor core)
Cycle Time	500 µs (for cyclical task)
Program memory	12 Mbyte
Data storage	32 Mbyte
Retentive data storage	1 Mbyte
PLC switch	RUN/STOP/RESET switch
Conformance with EMC Directive 2014/30/EU	
Immunity test in accordance with EN 61000-6-2/IEC 61000-6-2	
Electrostatic discharge (ESD) EN 61000-4-2/IEC 61000-4-2	Criterion B, 6 kV contact discharge, 8 kV air discharge
Electromagnetic fields EN 61000-4-3/IEC 61000-4-3	Criterion A, Field intensity: 10 V/m
Fast transients (burst) EN 61000-4-4/IEC 61000-4-4	Criterion B, 2 kV
Transient overvoltage (surge) EN 61000-4-5/IEC 61000-4-5	Criterion B, DC supply lines: ±0.5 kV/±0.5 kV (symmetrical/asymmetrical), fieldbus cable shield: ±1 kV
Conducted interference EN 61000-4-6/IEC 61000-4-6	Criterion A, Test voltage 10 V
Noise emission test according to EN 61000-6-3/IEC 61000-6-3	
Approvals	
For the current approvals, go to:	www.phoenixcontact.com/product/1069208
UL, USA / Canada (E238705)	cULus
Corrosive gas test	ISA S71.04.2013 G3 Harsh Group A, DIN EN 60068-2-60:2016-06 Method 4
Industrial Cyber Security (IITS2 029429 0027 Rev. 00)	Industrial IT Security, IACS Component IEC 62443-4-1:2018 IEC 62443-4-2:2019 PPP 15003B:2021 (IEC 62443-4-1: Full ML3 Process Profile) Configuration: Security Profile active

Manufacturer's declarations

For the current manufacturer's declarations, go to: www.phoenixcontact.com/product/1069208

A Appendix

A 1 Updating the firmware



For information on updating the firmware, please refer to the PLCnext Info Center.

- [Firmware update via the shell](#)
- [Firmware update via the web-based management](#)

A 2 Shell commands for controlling the firmware



For information on controlling the firmware (start, stop, restart) via shell commands, please refer to the [PLCnext Info Center](#).

A 3 Replacing the HTTPS certificate

You can replace the HTTPS certificate currently used for the controller with a third-party certificate. The HTTPS certificate comprises two files: `https_cert.pem` and `https_key.pem`.

To replace the files on the controller, proceed as follows:

- Open the SFTP client software (e.g., WinSCP).
- If necessary:
Enter the IP address of the controller in the “Computer name” input field.
- Log in as an administrator.

In the delivery state, the following access data is set:

User name: admin

Password: printed on the controller.

- Open the `/opt/plcnext/Security/Certificates/https` directory.

The two files `https_cert.pem` and `https_key.pem` are located in this directory.

- Replace the two files with the third-party certificate files.



Please note:

The third-party certificate files must have the same designation as the original files.

- If necessary, rename the third-party certificate files to `https_cert.pem` and `https_key.pem`.

A 4 Use of the AXC F 2152 controller under extreme ambient conditions

The AXC F 2152 controller has been tested successfully over 250 temperature change cycles in accordance with IEC 61131-2 in the range from -40°C to $+70^{\circ}\text{C}$.

The following conditions were observed:

- The Axioline F devices for all connecting cables were connected with a minimum conductor cross section of 0.5 mm^2
- The Axioline F station was assembled on a wall-mounted horizontal DIN rail
- Fans were used to ensure continuous movement of air in the control cabinet
- The Axioline F station was not exposed to vibration or shock
- The Axioline F station was operated with a maximum of 24.5 V (ensured by using regulated power supply units)




Figure 14-1 Temperature change cycle



Temperature in the control cabinet/ambient temperature



Cycle

B Appendix for document lists

B 1 List of figures

Section 3

Figure 3-1:	Components of the controller	14
Figure 3-2:	Administrator password on the controller	21
Figure 3-3:	Example: Axioline F station with AXC F 2152 controller	22
Figure 3-4:	Example: AXC F 3152 controller as PROFINET controller	23
Figure 3-5:	Example: AXC F 3152 controller as PROFINET device	24
Figure 3-6:	Connection and operating elements of the AXC F 1152 and AXC F 2152 controllers	25
Figure 3-7:	Connection and operating elements of the AXC F 3152 controller	26
Figure 3-8:	AXC F 1152 and AXC F 2152 controller printing	27
Figure 3-9:	AXC F 3152 controller printing	27
Figure 3-10:	Diagnostic and status indicators	29
Figure 3-11:	Mode selector switch on the AXC F 3152 controller	33
Figure 3-12:	Reset button (1)	34
Figure 3-13:	Sequence when resetting to default setting type 1, and LED indicators	35
Figure 3-14:	Sequence when resetting to default setting type 2, and LED indicators	35
Figure 3-15:	Internal basic circuit diagram for AXC F 1152 and AXC F 2152	39
Figure 3-16:	Internal basic circuit diagram AXC F 3152	40
Figure 3-17:	Ethernet interfaces (1)	41
Figure 3-18:	Ethernet interfaces (1)	41
Figure 3-19:	Terminal points for the supply voltage (communications voltage U_L)	42
Figure 3-20:	Structure of the AXL BS BK bus base module	43
Figure 3-21:	Structure of the AXC BS L 2 bus base module	43
Figure 3-22:	Structure of the AXC BS L 30 bus base module	44

Section 4

Figure 4-1:	Placing the module vertically	45
Figure 4-2:	Example: AXC F 2152 in horizontal (A) and vertical (B) installation position	47
Figure 4-3:	Example: Structure of an Axioline F station with the	

	AXC F 2152	48
Figure 4-4:	Example: Axioline F station with AXC F 3152 and left-aligned Axioline F extension module	49
Figure 4-5:	Example: Structure of a PLCnext Inline station with the AXC F 2152	50
Figure 4-6:	Mounting the bus base modules	51
Figure 4-7:	Snapping the controller into place	51
Figure 4-8:	Removing the upper marking field of the AXC F 1152 and AXC F 2152	52
Figure 4-9:	Inserting the SD card	53

Section 5

Figure 5-1:	Overload range with fall-back characteristic curve	54
Figure 5-2:	Overload range without fall-back characteristic curve	54
Figure 5-3:	Connecting a rigid conductor	55
Figure 5-4:	Connecting a flexible conductor	55
Figure 5-5:	Connecting the supply connector	56
Figure 5-6:	Connecting Ethernet	57

Section 6

Figure 6-1:	PLCnext Engineer user interface	59
Figure 6-2:	Start page, "Empty AXC F 2152 v.00 / 2020.0.0 project" project template	61
Figure 6-3:	Setting the IP address range	62
Figure 6-4:	Setting the IP address	63
Figure 6-5:	Selecting the network card	64
Figure 6-6:	Assigning online devices	64
Figure 6-7:	Successful assignment of the configured controller to an online device	65
Figure 6-8:	"SECURE DEVICE LOGIN" dialog	65
Figure 6-9:	Successful connection to the controller	66

Section 10

Figure 10-1:	Removing the module vertically	70
Figure 10-2:	Removing the cable	71
Figure 10-3:	Removing the supply connector	71
Figure 10-4:	Removing the SD card	72
Figure 10-5:	Removing the controller	73

Appendix A

Figure 14-1: Temperature change cycle 97

B 2 List of tables

Section 1

Table 1-1:	Temperature derating of the AXC F 2152 depending on the altitude	11
------------	--	----

Section 3

Table 3-1:	Special characteristics of the left-alignable extension modules in combination with the controllers	16
Table 3-2:	Controller diagnostic and status indicators	29
Table 3-3:	Controller operating modes	33
Table 3-4:	Terminal point assignment of the supply connector	42

Section 4

Table 4-1:	Recommended end brackets.....	46
------------	-------------------------------	----

B 3 Index

A

Applicative system redundancy	25
Axioline F station	48

B

Bus base module	43
-----------------------	----

C

Checking the delivery	13
Connection elements	25
Controller	
Defect	75
Mounting	51
Removing	73
Repair	75
Replacement	74

D

Decommissioning	76
Default settings	
Type 1	34
Type 2	35
Device defect	75
Device replacement	74
Diagnostic and status indicators	25, 26
DIN rail	46
Disposal	
Controller	76
Packaging	76
SD card	76

E

End bracket	46
Error diagnostics	29
Ethernet	
Connecting	57
Interfaces	41
Extension module	15

F

Fall-back characteristic curve	54
FAQs	77

File system	20
SFTP access	21
Firewall	22
Firmware update	69, 96
Flash memory, internal	36
Flash memory/SD card	18

H

Hardware	
Connecting and wiring	54
Mounting	45
Removing	70
Requirements	20
HTTPS certificate	96

I

Intended use	7
Internal basic circuit diagram	39
IP20	46

L

Left-alignable module	15
Left-alignment	15

M

Maintenance	76
Modifications	7
Modules	
Extension module	15
Left-alignable	15
Mounting	51
Mounting location	46
Mounting position	47

O

Open-source software	
Licensing information	20
Requesting source code	20
Operating elements	25
Overlay file system	36

P

PLCnext Engineer	
Connecting to the controller.....	64
IP settings.....	61
New project.....	60
User interface.....	59
Possible fields of application.....	22
Power supply	
Connecting.....	55
Power supply sizing.....	54
Power supply without fall-back characteristic curve	54
Printing.....	27
Product changes.....	7
PROFICLOUD V3.....	67
PROFINET controller/device functionality.....	15

R

Removing a connector.....	71
Removing cables.....	71
Removing connectors	
Ethernet connector.....	71
Supply connector.....	71
Repairs.....	75
Reset button.....	25, 26, 34
resetting the controller.....	34

S

Safety notes.....	7
Scope of supply.....	13
SD card.....	36
Inserting.....	52
Removing.....	72
SD card, pluggable.....	36
Security in the network.....	8
Sizing of the power supply.....	54
Status indicators.....	29
Storage.....	12
Supply connector	
Connecting.....	56
terminal point assignment.....	42

System variables.....	68
Axioline F.....	68
Device status.....	68
HMI_CONTROL.....	68
HMI_STATUS.....	68
INTERBUS.....	68
PROFINET.....	68
System time.....	68
Task handling.....	68
TCP_SOCKET, UDP_SOCKET, and TLS_SOCKET function blocks.....	68

T

Third-party certificate.....	96
Transport.....	12
Troubleshooting.....	77

U

UL warning notes.....	9
Unauthorized network access.....	8
Unpacking.....	12

W

WBM.....	69
----------	----

Please observe the following notes

General terms and conditions of use for technical documentation

Phoenix Contact reserves the right to alter, correct, and/or improve the technical documentation and the products described in the technical documentation at its own discretion and without giving prior notice, insofar as this is reasonable for the user. The same applies to any technical changes that serve the purpose of technical progress.

The receipt of technical documentation (in particular user documentation) does not constitute any further duty on the part of Phoenix Contact to furnish information on modifications to products and/or technical documentation. You are responsible to verify the suitability and intended use of the products in your specific application, in particular with regard to observing the applicable standards and regulations. All information made available in the technical data is supplied without any accompanying guarantee, whether expressly mentioned, implied or tacitly assumed.

In general, the provisions of the current standard Terms and Conditions of Phoenix Contact apply exclusively, in particular as concerns any warranty liability.

This manual, including all illustrations contained herein, is copyright protected. Any changes to the contents or the publication of extracts of this document is prohibited.

Phoenix Contact reserves the right to register its own intellectual property rights for the product identifications of Phoenix Contact products that are used here. Registration of such intellectual property rights by third parties is prohibited.

Other product identifications may be afforded legal protection, even where they may not be indicated as such.

How to contact us

Internet

Up-to-date information on Phoenix Contact products and our Terms and Conditions can be found on the Internet at:

phoenixcontact.com

Make sure you always use the latest documentation.

It can be downloaded at:

phoenixcontact.com/products

Subsidiaries

If there are any problems that cannot be solved using the documentation, please contact your Phoenix Contact subsidiary.

Subsidiary contact information is available at phoenixcontact.com.

Published by

Phoenix Contact GmbH & Co. KG

Flachsmarktstraße 8

32825 Blomberg

GERMANY

Should you have any suggestions or recommendations for improvement of the contents and layout of our manuals, please send your comments to:

tecdoc@phoenixcontact.com

Phoenix Contact GmbH & Co. KG
Flachmarktstraße 8
32825 Blomberg, Germany
Phone: +49 5235 3-00
Fax: +49 5235 3-41200
Email: info@phoenixcontact.com
phoenixcontact.com